



neptronic®

SKE4 Steam Humidifier

Modbus Communication Module User Guide





Introduction

The SKE4 Modbus Communication Module User Guide provides information for using Neptronic® communication feature. The controller uses Modbus communication protocol over serial line in the RTU mode and provides a Modbus network interface between client devices and Neptronic SKE4 devices.

The SKE4 Modbus Guide assumes that you are familiar with Modbus terminology.

The following are the requirements for Modbus:

- **Data Model.** The SKE4 Steam Humidifier Modbus server data model uses only the Modbus Registers table.
- **Register Address:**
 - As per protocol base (base 0); for PLC add 1 to protocol base.
 - As per holding register (base 40001).
- **Function Codes.** The SKE4 Steam Humidifier Modbus server supports a limited function codes subset comprising:
 - Read Holding Registers (0x03)
 - Write Single Register (0x06)
 - Write Multiple Registers (0x10)
- **Exception Responses.** The SKE4 Steam Humidifier Modbus server supports the following exception codes:
 - Illegal data address
 - Illegal data value
 - Slave device busy
- **Serial Line.** The SKE4 Steam Humidifier Modbus over serial line uses RTU transmission mode over a two-wire configuration RS485 (EIA/TIA-485 standard) physical layer.
 - The physical layer can use fixed baud rate selection or automatic baud rate detection (default) as per the **Modbus Auto Baud Rate** device menu item or holding register index 1.
 - The supported baud rates are 9600, 19200, 38400, and 57600.
 - The physical layer also supports variable parity control and stop bit configuration as per the **Modbus Comport Config** device menu item or holding register index 2.
 - In auto baud rate configuration, if the device detects only consecutive bad frames (2 or more) for one second with any given baud rate, it will reinitialize itself to the next baud rate.
- **Addressing.** The SKE4 Steam Humidifier device only answers at the following address:
 - The device's unique address (1 to 246) that can be set through the device menu or through holding register index 0.

Modbus Registers

Table Glossary

Name	Description	Name	Description
W	Writable Register	ASCII	For registers containing ASCII (8-bit) characters
RO	Read Only Register	MSB	Most Significant Byte
Unsigned	For range of values from 0 to 65,535, unless otherwise specified	LSB	Least Significant Byte
Signed	For range of values from -32,768 to 32,767, unless otherwise specified	MSW	Most Significant Word
Bit String	For registers with multiple values using bit mask (example, flags)	LSW	Least Significant Word

Modbus Registers Table

Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
0	400001	Modbus Address and Product Type	Unsigned	MSB = Product type, not writable LSB = Modbus Address (1 to 247), writable	W	
1	400002	Device Baud Rate	Unsigned <i>Scale 100</i>	0, 9600, 19200, 38400, and 57600, 0 = Auto <i>Baud Rate Detection Value/100 (e.g. 38400 baud = 384)</i>	W	19200
2	400003	Modbus Slave Communication Port Configuration	Unsigned	0 = No parity, 2 Stop bits 1 = Even parity, 1 Stop bit 2 = Odd parity, 1 Stop bit	W	No parity, 2 Stops bits
3	400004	Product Name (characters 8 & 7)	ASCII	MSB = char 6, LSB = char 7	W	
4	400005	Product Name (characters 6 & 5)	ASCII	MSB = char 4, LSB = char 5	W	
5	400006	Product Name (characters 4 & 3)	ASCII	MSB = char 2, LSB = char 3	W	
6	400007	Product Name (characters 2 & 1)	ASCII	MSB = char 0, LSB = char 1	W	



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
7	400008	Product Actual Firmware Version (in Integer x100)	Unsigned Scale 100	1 to 65535 (e.g. 100)	RO	
8	400009	Product Actual EEPROM Version (in Integer x100)	Unsigned Scale 100	1 to 65535 (e.g. 100)	RO	
2000	402001	Control Signal	Unsigned Scale 1000	0 to 10500 Value x 1000 (e.g. 1V = 1000)	RO	0
2001	402002	Room RH Signal	Unsigned Scale 1000	0 to 10500 Value x 1000 (e.g. 1V = 1000)	RO	0
2002	402003	Supply RH Signal	Unsigned Scale 1000	0 to 10500 Value x 1000 (e.g. 1V = 1000)	RO	0
2003	402004	Water Level Signal	Unsigned Scale 1	0 to 30000 Value x 1 (e.g. 10Hz = 10)	RO	0
2004	402005	Water Level Low Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2005	402006	Water Level High Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2006	402007	Water Temperature Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2007	402008	Foam Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2008	402009	SSR Temperature Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2009	402010	Cabinet Temperature Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2010	402011	Current Sensor 1 Signal	Unsigned Scale 1000	0 to 3300 Value x 1000 (e.g. 1V = 1000)	RO	0



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
2011	40 2012	Current Sensor 2 Signal	Unsigned Scale 1000	0 to 3300 Value x 1000 (e.g. 1V = 1000)	RO	0
2012	40 2013	Board Temperature Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
2013	40 2014	Main Power Supply	Unsigned Scale 10	0 to 400 Value x 10 (e.g. 1V = 10)	RO	0
4000	40 4001	Power Output Feedback Signal	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 1V = 1000)	RO	0
4001	40 4002	Heater SSR Stage	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	RO	0
6000	40 6001	Control Input	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	RO	0
6001	40 6002	Room RH	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	RO	0
6002	40 6003	Supply High Limit RH	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	RO	0
6003	40 6004	Water Temperature Signal Min	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 10V = 10000)	RO	0
6004	40 6005	Water Temperature Signal Max	Unsigned Scale 1000	0 to 10000 Value x 1000 (e.g. 10V = 10000)	RO	3000
6005	40 6006	Water Temperature	Unsigned Scale 100	0 to 12500 Value x 100 (e.g. 10C = 1000)	RO	5000
6006	40 6007	Water Temperature Min	Unsigned Scale 100	0 to 25000 Value x 100 (e.g. 10C = 1000)	RO	0
6007	40 6008	Water Temperature Max	Unsigned Scale 100	0 to 25000 Value x 100 (e.g. 10C = 1000)	RO	12500



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
6008	406009	Water Temperature Bias	Signed Scale 100	-1000 to 1000 Value x 100 (e.g. 10C = 1000)	RO	0
6009	406010	SSR Temperature	Signed Scale 100	-2000 to 10000 Value x 100 (e.g. 10C = 1000)	RO	0
6010	406011	Cabinet Temperature	Signed Scale 100	-200 to 1000 Value x 100 (e.g. 1C = 100)	RO	0
6011	406012	Current Sensor 1 (0)	Unsigned Scale 100	0 to 15000 Value x 100 (e.g. 10A = 1000)	RO	0
6012	406013	Current Sensor 1 (1)		0 to 15000		
6013	406014	Current Sensor 2 (0)	Unsigned Scale 100	0 to 15000 Value x 100 (e.g. 10A = 1000)	RO	0
6014	406015	Current Sensor 2 (1)		0 to 15000		
6015	406016	Board Temperature	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10C = 1000)	RO	0
6016	406017	Power Output Feedback	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	RO	0
6017	406018	Water Level	Unsigned Scale 10	0 to 2000 Value x 10 (e.g. 10% = 100)	RO	780
6018	406019	Water Probe Low Pos Reading	Unsigned Scale 1	0 to 30000 Value x 1 (e.g. 1 Hz = 1)	RO	30000
6019	406020	Water Probe High Pos Reading	Unsigned Scale 1	0 to 30000 Value x 1 (e.g. 1 Hz = 1)	RO	30000
6020	406021	Water Probe Abs Low Pos Reading	Unsigned Scale 1	0 to 30000 Value x 1 (e.g. 1 Hz = 1)	RO	30000
6021	406022	Water Probe Abs High Pos Reading	Unsigned Scale 1	0 to 30000 Value x 1 (e.g. 1 Hz = 1)	RO	30000



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
6022	406023	Room RH Network Reading	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	RO	0
6023	406024	Room RH Setpoint	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	W	4000
6024	406025	Room RH Unoccupied Setpoint	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	W	3000
6025	406026	Room RH Vacant Setpoint	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	W	2000
6026	406027	Room Demand	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	RO	0
6027	406028	Supply High Limit Network Reading	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	W	0
6028	406029	Supply High Limit Setpoint	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% hum = 1000)	W	8000
6029	406030	Supply High Limit Demand	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	RO	0
6030	406031	Humidity Control Network Demand	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	W	0
6031	406032	Humidity Control Network High Limit	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	W	10000
6032	406033	Humidity Demand	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	RO	0
6033	406034	SDU Fan Off Delay	Unsigned Scale 1	5 to 20 Value x 1 (e.g. 5min = 5)	W	5
6034	406035	Humidity Demand Low Dead Band (0)	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 10% = 1000)	W	100
6035	406036	Humidity Demand Low Dead Band (1)		0 to 10000 Value x 100 (e.g. 10% = 1000)		



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
6036	406037	Control Network Timeout (0)	Unsigned Scale 1	1 to 15 <i>Value x 1 (e.g. 5min = 5)</i>	W	15
6037	406038	Control Network Timeout (1)		1 to 15 <i>Value x 1 (e.g. 5min = 5)</i>		
6038	406039	System Power Output	Unsigned Scale 100	0 to 10000 <i>Value x 100 (e.g. 10% = 1000)</i>	RO	0
6039	406040	System Steam Capacity	Unsigned Scale 10	0 to 30000 <i>Value x 10 (e.g. 10 kg/h = 100)</i>	RO	0
6040	406041	Boiler Demand	Unsigned Scale 100	0 to 10000 <i>Value x 100 (e.g. 10% = 1000)</i>	W	0
6041	406042	Boiler Capacity	Unsigned Scale 10	0 to 30000 <i>Value x 10 (e.g. 10kg/hr = 100)</i>	RO	160
6042	406043	Boiler Power Output	Unsigned Scale 100	0 to 10000 <i>Value x 100 (e.g. 10% = 1000)</i>	RO	0
6043	406044	Boiler Run Time (0)	Unsigned Scale 100	0 to 2147483647 <i>Value x 100 (e.g. 10h = 1000)</i>	RO	0
6044	406045	Boiler Run Time (1)		0 to 2147483647		
6045	406046	Boiler Run Time (2)		0 to 2147483647		
6046	406047	Boiler Run Time (3)		0 to 2147483647		
6047	406048	Boiler On Time (0)	Unsigned Scale 100	0 to 2147483647 <i>Value x 100 (e.g. 10h = 1000)</i>	RO	0
6048	406049	Boiler On Time (1)		0 to 2147483647		
6049	406050	Boiler On Time (2)		0 to 2147483647		
6050	406051	Boiler On Time (3)		0 to 2147483647		
6051	406052	Boiler Service Run Time (0)	Unsigned Scale 100	0 to 2147483647 <i>Value x 100 (e.g. 10h = 1000)</i>	RO	0



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
6052	406053	Boiler Service Run Time (1)		0 to 2147483647		
6053	406054	Boiler Service Run Time (2)		0 to 2147483647		
6054	406055	Boiler Service Run Time (3)		0 to 2147483647		
6055	406056	Boiler Service On Time (0)	Unsigned Scale 100	0 to 2147483647 Value x 100 (e.g. 10h = 1000)	RO	0
6056	406057	Boiler Service On Time (1)		0 to 2147483647		
6057	406058	Boiler Service On Time (2)		0 to 2147483647		
6058	406059	Boiler Service On Time (3)		0 to 2147483647		
6059	406060	Boiler Minimum Steam Output	Unsigned Scale 1	1 to 25 Value x 1 (e.g. 1% = 1)	W	5
6060	406061	Boiler Drain Interval	Unsigned Scale 1	0 to 24 Value x 1 (e.g. 1h = 1)	W	6
6061	406062	Boiler Drain Volume	Unsigned Scale 1	25 to 100 Value x 1 (e.g. 1% = 1)	W	100
6062	406063	Boiler Max Steam Output	Unsigned Scale 1	0 to 100 Value x 1 (e.g. 1% = 1)	W	100
6063	406064	Boiler Idle Time Drain	Unsigned Scale 1	0 to 72 Value x 1 (e.g. 1h = 1)	W	24
6064	406065	Boiler Idle Temperature Setpoint	Unsigned Scale 1	0 to 60 Value x 1 (e.g. 1°C = 1)	W	0
6065	406066	Boiler Blowdown Rate	Unsigned Scale 1	0 to 100 Value x 1 (e.g. 1% = 1)	W	0
6066	406067	Boiler Service Interval	Unsigned Scale 1	1000 to 3000 Value x 1 (e.g. 1h = 1)	W	1000



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
6067	406068	Boiler Idle Tank Rinse Interval	Unsigned Scale 1	1 to 7 Value x 1 (e.g. 1 day = 1)	W	3
6068	406069	Boiler Anti-Freeze Drain (0)	Signed Scale 100	-4000 to 10000 Value x 100 (e.g. 1C = 100)	RO	100
6069	406070	Boiler Anti-Freeze Drain (1)		-4000 to 10000 Value x 100 (e.g. 1C = 100)		
6070	406071	Boiler Anti-Freeze Keep Warm Setpoint (0)	Signed Scale 100	-4000 to 10000 Value x 100 (e.g. 1C = 100)	RO	3000
6071	406072	Boiler Anti-Freeze Keep Warm Setpoint (1)		-4000 to 10000 Value x 100 (e.g. 1C = 100)		
6072	406073	Boiler Anti-Freeze Keep Warm (0)	Signed Scale 100	-4000 to 10000 Value x 100 (e.g. 1C = 100)	RO	1000
6073	406074	Boiler Anti-Freeze Keep Warm (1)		-4000 to 10000 Value x 100 (e.g. 1C = 100)		
6074	406075	HRL Temperature	Signed Scale 100	-4000 to 26000 Value x 100 (e.g. 1C = 100)	RO	0
6075	406076	HRL Humidity	Unsigned Scale 100	0 to 10000 Value x 100 (e.g. 1% = 100)	RO	0
10000	410001	Air Flow	Unsigned Scale 1	0 = Closed 1 = Open	RO	Closed
10001	410002	Supply High Limit	Unsigned Scale 1	0 = Closed 1 = Open	RO	Closed
10002	410003	Interlock	Unsigned Scale 1	0 = Closed 1 = Open	RO	Closed
10003	410004	Binary External Demand	Unsigned Scale 1	0 = 0% 1 = 100%	RO	0%
10004	410005	Water Leak Detection	Unsigned Scale 1	0 = Ok 1 = Leak	RO	Ok

Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
10005	410006	Thermal Cutout	Unsigned Scale 1	0 = Closed 1 = Open	RO	Closed
10006	410007	RS485 Interface	Unsigned Scale 1	0 = No 1 = Yes	RO	No
10007	410008	Ethernet Interface	Unsigned Scale 1	0 = No 1 = Yes	RO	No
10008	410009	Contactors PCB Fuse	Unsigned Scale 1	0 = Normal 1 = Blown Fuse	RO	Normal
10009	410010	Control PCB Fuse	Unsigned Scale 1	0 = Normal 1 = Open Fuse	RO	Normal
11000	411001	Alarm Warning Relay	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11001	411002	Service Warning Relay	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11002	411003	Water Level Valve	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11003	411004	Tank Water Valve	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11004	411005	Drain Cooler Valve	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11005	411006	Drain Pump	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11006	411007	Drain Valve	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11007	411008	Main Contactor	Unsigned Scale 1	0 = Off 1 = On	RO	Off



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
11008	411009	Heater Stage 1	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11009	411010	Heater Stage2	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11010	411011	Heater Stage 3	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11011	411012	SDU Fan	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11012	411013	Alarm LED	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11013	411014	Power LED	Unsigned Scale 1	0 = Off 1 = On	RO	Off
11014	411015	Buzzer	Unsigned Scale 1	0 = Off 1 = On	RO	Off
12000	412001	System Production Test Done	Unsigned Scale 1	0 = Inactive 1 = Active	RO	Inactive
12001	412002	Network Control State	Unsigned Scale 1	0 = Normal 1 = Fault	W	Normal
12002	412003	Water Level Low	Unsigned Scale 1	0 = Inactive 1 = Active	RO	Inactive
12003	412004	Water Level High	Unsigned Scale 1	0 = Inactive 1 = Active	RO	Inactive
12004	412005	Foam Sensor	Unsigned Scale 1	0 = NoFoam 1 = Foam	RO	NoFoam
12005	412006	SDU Fan Fault	Unsigned Scale 1	0 = Off 1 = On	RO	Off



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
12006	412007	Boiler Service Operation	Unsigned Scale 1	0 = Not Allowed 1 = Allowed	W	Allowed
12007	412008	Boiler Service Due	Unsigned Scale 1	0 = Off 1 = On	RO	Off
12008	412009	Boiler Foam State	Unsigned Scale 1	0 = NotFoaming 1 = Foaming	RO	NotFoaming
12009	412010	HRL Lock Setpoint	Unsigned Scale 1	0 = Unlock 1 = Lock	W	Unlock
15000	415001	System Log Verbose Level	Unsigned Scale 1	0 = None 1 = Emergency 2 = Alert 3 = Critical 4 = Error 5 = Warning 6 = Notice 7 = Info 8 = Debug	W	Debug
15001	415002	Modbus Server Units	Unsigned Scale 1	0 = Metric 1 = Imperial	W	Metric
15002	415003	Control Profile	Unsigned Scale 1	0 = ExternAnalog 1 = ExternNetwork 2 = InternAnalog 3 = InternNetwork 4 = HRL 5 = Custom	W	ExternAnalog
15003	415004	Modulating High Limit Profile	Unsigned Scale 1	0 = Disabled 1 = ExternAnalog 2 = ExternNetwork 3 = InternAnalog 4 = InternNetwork 5 = Custom	W	Disabled
15004	415005	Occupancy State	Unsigned Scale 1	0 = Occupied 1 = Unoccupied 2 = Vacant 3 = Off	RO	Occupied
15005	415006	Room RH Source	Unsigned Scale 1	0 = None 1 = RoomRH 2 = Network	W	None
15006	415007	Room RH Setpoint Source	Unsigned Scale 1	0 = None 1 = Internal 2 = ControllInput	W	None



Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
15007	415008	Supply High Limit Reading Source	Unsigned Scale 1	0 = None 1 = SupplyHLRH 2 = Network	W	None
15008	415009	Supply High Limit Setpoint Source	Unsigned Scale 1	0 = None 1 = Internal 2 = ControllInput	W	None
15009	415010	Humidity Control Demand Source	Unsigned Scale 1	0 = None 1 = ControllInput 2 = RoomDemand 3 = Network	W	ControllInput
15010	415011	Humidity Control High Limit Source	Unsigned Scale 1	0 = None 1 = ControllInput 2 = SupplyHLDemand 3 = Network	W	None
15011	415012	Humidity Control Cutout State	Unsigned Scale 1	0 = Off 1 = Normal 2 = LowLimit 3 = HighLimit 4 = NoAirFlow 5 = Interlock	RO	Off
15012	415013	SDU Fan Target	Unsigned Scale 1	0 = None 1 = SDUFan	W	None
15013	415014	Boiler Power State	Unsigned Scale 1	0 = Off 1 = On	RO	Off
15014	415015	Boiler Request	Unsigned Scale 1	0 = None 1 = Reset Alarms 2 = Drain 3 = Reset Counters 4 = Filling 5 = WaterCalib	W	None
15015	415016	Boiler State	Unsigned Scale 1	0 = Off 1 = Idle 2 = LineRinse 3 = TankRinse 4 = Filling 5 = Draining 6 = Heating 7 = Boiling 8 = Alarm	RO	Off
15016	415017	Boiler Fill Mode	Unsigned Scale 1	0 = OneShot 1 = Pulsed	W	Pulsed
15017	415018	Boiler Alarm	Unsigned Scale 1	0 = Normal 1 = FailedPump 2 = FillTimeout 3 = BlockedPiping 4 = HeatTimeout 5 = Overheat 6 = WaterLeak 7 = Service 8 = Foaming	RO	Normal

Protocol Base	Holding Register	Description	Data Type	Units, Limits, State Texts	Writable	Default Value
15018	415019	Boiler Idle Tank Rinse On	Unsigned <i>Scale 1</i>	0 = Off 1 = On	W	Off
15019	415020	Boiler Idle Tank Rinse Off	Unsigned <i>Scale 1</i>	0 = Off 1 = On	W	Off
15020	415021	Water Probe Auto Calib.	Unsigned <i>Scale 1</i>	0 = None 1 = Once 2 = Always	W	Always
15021	415022	Boiler Startup Tank Rinse	Unsigned <i>Scale 1</i>	0 = Off 1 = On	W	Off



neptronic®

400 Lebeau blvd, Montreal, Qc, H4N 1R6, Canada

www.neptronic.com

Toll free in North America: 1-800-361-2308

Tel.: (514) 333-1433

Fax: (514) 333-3163

Customer service fax: (514) 333-1091

Monday to Friday: 8:00am to 5:00pm (Eastern time)