



Installation Instructions and User Manual

Read and save this manual







#### Installation Instructions and User Manual

### **Foreword**

### **Neptronic Company Overview**

Founded in 1976, Neptronic is a private corporation that designs, manufactures and distributes products for the HVAC industry. Our product line includes intelligent controllers, electronic actuators, actuated valves, humidifiers and electric heaters.

Our products are designed and manufactured by over 250 dedicated employees in our 7,500 m<sup>2</sup> (80,000 ft<sup>2</sup>) state-of-theart facility located in Montreal, Canada. Our entire manufacturing chain is under one roof from software and hardware development to SMT circuit board assembly, to sheet metal fabrication, to product testing ensuring that our products are engineered to last using a vertical integration model.

We currently hold several national and international patents, and with our continued commitment to research and development, we provide innovative products and technologies for the ever-evolving challenges of the HVAC industry. Exporting over 85% of our sales, we have an exclusive distribution network around the globe that provides comprehensive solutions to our worldwide customers.

#### **About the Manual**

These installation and operation instructions have been developed to facilitate the installation of the SKH High-Pressure Atomizer humidifier.

- The strict application of these instructions ensures conformity of your installation and operation as per the manufacturer's recommendations.
- The application of these instructions is one of the conditions for the application of the warranty.
- The application of these instructions does not ensure, at any time, conformity to procedures, regulation or local codes, regarding electric connections and installation to local water supply.

This product has been declared to conform to the applicable Canadian and American safety standards and directives and bear the ETL (c) & (us) mark. The Certificate of Conformity for ETL is available, upon request with the manufacturer.

This product has been declared to conform to the applicable European safety and electromagnetic compatibility standards and directives and bear the CE mark. The Certificate of Conformity for CE is available, upon request to the manufacturer.

### **Copyright Information**

Copyright ©2018 by Neptronic.

All rights reserved. This document cannot be reproduced wholly or partially by any means, whether electronic, mechanical, photocopy, recording or other, without prior written authorization of Neptronic.



Installation Instructions and User Manual

# **Health and Safety Instructions**

#### General

This manual has been written to ensure correct, safe and sustainable operation of the SKH High-Pressure Atomiser and is intended for use by engineers and technical personnel trained by or their official agents. This manual must be read thoroughly before specifying, designing, installing or operating a SKH High-Pressure Atomizer. Please retain for reference and contact Neptronic should you have any questions.



The triangular symbol with the word **WARNING**: is used to designate danger of severe or lethal consequence.



The circular symbol with the word **CAUTION**: is used to designate danger of injury, or to warn of the hazardous operating condition, or other relevant information.

### **Electrical Warning Message**



#### WARNING

- Risk of electric shock. Do not access. Disconnect SKH High-Pressure Atomizer before opening the access
  door.
- All work concerned with electrical installation MUST only be performed by skilled and qualified technical
  personnel (such as an electrician or a technician with appropriate training). The customer is always
  responsible for ensuring the suitability of the technical personnel.
- Please observe the local regulations concerning the provision of electrical installations.

### **Health & Safety**

Installation, maintenance, repair work or de-commissioning should only be carried out by appropriately qualified technical personnel. Any risks or hazards relating to the system, including during installation and maintenance, should be identified by a qualified Health & Safety representative who shall be responsible for introducing effective control measures, as necessary. The customer is responsible for ensuring that the installation of the equipment complies with all local regulations.



**CAUTION**: Maintenance personnel must be trained by Neptronic or their official agent, and it is the customer's responsibility to ensure their suitability. Failure to use a qualified personnel may lead to a hazardous operating condition.



**WARNING**: Danger of Electrocution! Danger of contact with live parts when the unit is open. Always isolate all water and electrical supplies to the system before commencing any maintenance or repair. Isolate power and water immediately if there is any sign of water leaking from the unit.

### **Protective Equipment**

Please refer to the Health and Safety Executive for recommendations about Personal Protective Equipment and information on the Control of Substances Hazardous to Health (COSHH).



#### Installation Instructions and User Manual

### Hygiene

#### **IMPORTANT:**

Refer to local Health and Safety regulation and codes on the control of Legionellosis in water systems. In the absence of such, ASHREA guideline 12-2000 does provide recommendations. If not adequately maintained, water systems can support the growth of microorganisms including the bacterium that causes Legionnaires' disease.

The SKH has been designed to reduce the potential risk of legionellosis growth. Users also share the responsibility for reducing the risk of legionellosis; users are required to:

- Conduct a risk assessment of the complete water system.
- Implement proper control of the water system.
- Connect the SKH to a clean and chlorinated water supply main.
- Avoid stagnant water.
- Avoid water temperatures that increase the risk of Legionella growth.
- Clean and disinfect the system regularly.



WARNING: Risk of Legionnaires' disease, which can be fatal. Install and operate the SKH High-Pressure Atomizer as per the instructions given in this Installation Instructions and User Manual.



WARNING: If the SKH High-Pressure Atomizer is turned off for prolonged periods (more than 24 hours), ensure that any piping supplying the unit is drained, unless they supply other systems which ensure a regular renewal of water in the system. Failure to do so may result in stagnation of the water and contamination that might cause Legionnaires' disease, which can be fatal.

It is the responsibility of the person on whom the statutory responsibility falls to determine all control and preventative measures outlined in this manual.

#### **Correct Use**

Neptronic systems and products are designed only for humidification use. Any other application is not considered appropriate for the intended purpose. The manufacturer cannot be made liable for any damage resulting from incorrect use.

### **Important Start-Up Information**

Before turning on and operating the SKH High-Pressure Atomizer:

- Read all instructions and installation procedures outlined in this manual. Ensure that the operation of the system is properly understood before commencing the start-up procedure.
- Ensure that all wiring is properly installed and that all connections have been made correctly, including the network communication cable between the pump station and the EZC controller(s). Proper termination and shield wiring is critical to the operation of the system.
- Verify all piping before starting up the system. As each zone may have a different capacity and the system has been configured as such, connecting the wrong EZC output to a zone may lead to erratic operation.

### **General Warranty**

This product is subject to the terms and conditions described at <a href="https://www.neptronic.com/sales-conditions.aspx">www.neptronic.com/sales-conditions.aspx</a>.

Page | iii www.neptronic.com



# **SKH High-Pressure Atomizer** Installation Instructions and User Manual

# **Contents**

| Overview  | 5  |
|---|----|
| Product Description                                     |    |
| Benefits  |    |
| Features  |    |
| SKH Pump Station Overview                               | 6  |
| Specifications  |    |
| Handling and Packaging                                  |    |
| Handling and Lifting                                    |    |
| Correct Lifting Method                                  |    |
| Inspection  |    |
| Unpacking   |    |
| Installation Overview                                   | 9  |
| Local Regulations                                       | 9  |
| List of Supplied Accessories                            | 9  |
| Installation Method Statement                           | 10 |
| Step 1 – SKH Pump Station Installation                  |    |
| Step 2 – Electronic Zone Controller (EZC) Installation  | 12 |
| Step 3 – Mist Distribution Ramp and Nozzle Installation |    |
| Step 4 – Water and Drain Connections                    |    |
| Step 5 – Power Supply Connections                       |    |
| Step 6 – Electrical Control Connections                 | 28 |
| Step 7 – Controller Installation and Configuration      |    |
| Start-Up Procedure                                      |    |
| Initial Verification                                    | 47 |
| Start-Up  | 49 |
| Servicing and Maintenance                               |    |
| Preventive Maintenance                                  |    |
| Replacement Part Numbers                                |    |



Installation Instructions and User Manual

# **Overview**

# **Product Description**

The SKH High-Pressure Atomizer uses water through a high-pressure system to produce a fine mist with a droplet size of less than 20µm. The ambient air absorbs the fine mist, and the SKH adapts to seasonal changes to provide direct evaporative cooling in summer and humidification in winter. Additionally, the SKH provides BACnet MS/TP communication, multi-zone operation (up to 10 zones) and remote connection to the entire system from any zone.

### **Benefits**

- Very low energy consumption
- Free cooling up to 21.5°F (12°C)
- Hygienic operation
- Environmentally friendly
- Low pressure drop
- All parts in contact with water are made of stainless steel and designed for life

### **Features**

The following are the features of the SKH High-Pressure Atomizer:

- 5 microns PP pre-filter and silver ion dosing cartridges prevent microbial growth
- BACnet communication (optional)
- Master/Slave configuration for up to 4 pump stations
- User-friendly, menu-driven LCD (128 x 64)
- Real-time clock and SD card for schedule, trending, and history log
- Firmware upgrade using an SD card
- Water overflow outlet (optional)



# **SKH Pump Station Overview**




Illustration 1 - SKH Pump Station Visual Overview




Illustration 2 - SKH Pump Station Overview



# **Specifications**

Table 1 - Pump Station Dimensions & Weight

| Model   | Capacity range<br>lb/hr (kg/hr) | С       | Weight<br>lb (kg) |                     |           |
|---------|---------------------------------|---------|-------------------|---------------------|-----------|
|         | ib/iii (kg/iii)                 | Α       | В                 | С                   | in (kg)   |
| SKH100  | 66 (30) to<br>660 (300)         | 30      | 36                | 20                  | 107 (05)  |
| SKH200  | 141 (64) to<br>1126 (512)       | (763) ( | (915)             | (508)               | 187 (85)  |
| SKH300  | 231 (105) to<br>1454 (661)      |         |                   | 46 24<br>156) (622) | 209 (95)  |
| SKH600  | 453 (206) to<br>2343 (1065)     | 34      | 46                |                     |           |
| SKH900  | 585 (266) to<br>3645 (1657)     | (871)   | (1156)            |                     |           |
| SKH1200 | 805 (366) to<br>4738 (2108)     |         |                   |                     | 220 (100) |




Illustration 3 - Pump Station Dimensions & Weight

Table 2 - Electronic Zone Controller (EZC) Dimensions & Weight

| Model | No. supply | С             | Dimensions in (mm) | Weight       |         |
|-------|------------|---------------|--------------------|--------------|---------|
|       |            | Α             | В                  | С            | lb (kg) |
| EZC1  | 1          | 14.3<br>(362) | 13.9<br>(353)      | 6<br>(152)   | 7 (3)   |
| EZC2  | 2          | 17.1<br>(434) | 13.9<br>(353)      | 6<br>(152)   | 11 (5)  |
| EZC3  | 3          | 19.9<br>(505) | 13.9<br>(353)      | 6<br>(152)   | 15 (7)  |
| EZC4  | 4          | 22.6<br>(575) | 13.9<br>(353)      | 6.1<br>(154) | 20 (9)  |




Illustration 4 - Electronic Zone Controller (EZC)
Dimensions & Weight



#### Installation Instructions and User Manual

# **Handling and Packaging**

## **Handling and Lifting**

Lifting or Handling MUST be carried out by trained and qualified personnel. Ensure that the lifting operation has been properly planned, assessed for risk and that the equipment is checked by a qualified Health & Safety representative, and effective control measures are in place.



It is the customer's responsibility to ensure that the operators are trained in handling heavy goods and to enforce the relevant lifting regulations.

The SKH High-Pressure Atomizer MUST always be handled and lifted with care and should remain in its original packaging for as long as possible before installation.

The SKH High-Pressure Atomizer package may be carried using a forklift from the underside. Caution should be exercised to ensure balanced load before lifting.

## **Correct Lifting Method**

Any personnel handling or lifting the SKH High-Pressure Atomizer must follow the Lifting Operations and Lifting Equipment Regulations 1998 and Approved Code of Practice L113. The regulation imposes duties on employers and self-employed persons and authorities who have control, to any extent of lifting equipment.

Refer to Dimensions and Weights as indicated on the nameplate and the submittal drawing for system dry weights.

### Inspection

Upon receipt, and once packaging material is removed, carry out an inspection to ensure that no damage occurred during transit. Report any damage immediately to your Neptronic representative.

# Unpacking

The SKH pump station is delivered in a crate. The Electronic Zone Controller, Mist Distribution Ramps, and the Nozzles are delivered in a carton.



#### Installation Instructions and User Manual

# **Installation Overview**



WARNING: Failure to observe manufacturer's installation recommendations voids the manufacturer's warranty.

# **Local Regulations**

Lifting or Handling MUST be carried out by trained and qualified personnel. Ensure that the lifting operation has been properly planned, assessed for risk and that the equipment is checked by a qualified Health & Safety representative, and that effective control measures are in place.



It is the customer's responsibility to ensure that the operators are trained in handling heavy goods and to enforce the relevant lifting regulations.

The SKH pump station MUST always be handled and lifted with care and should remain in its original packaging for as long as possible before installation.

The SKH pump station package may be carried using a forklift from the bottom. Caution should be exercised to ensure a balanced load before lifting.

# **List of Supplied Accessories**

- Water filter assembly
- 5 microns PP pre-filter
- Silver ion dosing anti-bacterial cartridges or UV light (depending on model)

Installation Instructions and User Manual



Installation Instructions and User Manual

# **Installation Method Statement**

- Step 1 SKH Pump Station Installation
- Step 2 Electronic Zone Controller (EZC) Installation
- Step 3 Mist Distribution Ramp and Nozzle Installation
- Step 4 Water and Drain Connections
- Step 5 Power Supply Connections
- Step 6 Electrical Control Connections
- Step 7 Controller Installation and Configuration




Illustration 5 - Installation Steps



### Installation Instructions and User Manual

# Step 1 - SKH Pump Station Installation

### **General Recommendations**



WARNING: Risk of electric shock. Disconnect the appliance from the electric supply before commencing installation.



CAUTION: Risk of injury. The SKH pump station is heavy; It MUST always be handled and lifted with care.

#### Location

Consider the following points before deciding the location for the pump station:

- Plan a location that is easy to access to permit an easy inspection and servicing of the pump station.
- Do not install the pump station where the failure of the appliance could cause damage to the building structure or other expensive equipment.
- Ensure that the location is ventilated appropriately and that the ambient temperature is less than 86°F (30°C).

#### **Positioning**

- There is no required minimum safety clearance.
- Provide a minimum clearance of 47" (1.20 m) on the front of the pump station, in order to permit access to connections and allow for servicing.
- It is recommended (but not mandatory) to allow some clearance on both sides and on the top of the SKH pump station for ease of service.
- The SKH pump station must be floor mounted.

#### Floor Mounting

- Provide a level, solid foundation for the SKH pump station.
- Ensure that the floor beneath the SKH pump station is waterproof to withstand any water spillage during servicing or if a problem occurs.
- Ensure that the SKH pump station is provided with adjustable legs to ensure proper level from the ground.
- Allow some space beneath the pump station for the drain pan connection, located below the bottom plate.



# Step 2 – Electronic Zone Controller (EZC) Installation



WARNING: Risk of electric shock. Disconnect the appliance from the electric supply before commencing installation.

#### Location

- Plan a location that is easy to access and permits an easy inspection and servicing of the EZC zone controller.
- Do not install the EZC zone controller where failure of the valve could cause damage to the building structure or to other expensive equipment.
- Ensure that the location is ventilated appropriately and that the ambient temperature is less than 86°F (30°C).

### **Positioning**


- There is no minimum clearance required for safety purposes.
- Provide a minimum clearance of 31" (0.80 m) on the front of the EZC zone controller, in order to permit access to connections and allow for servicing.
- It is recommended (but not mandatory) to allow some clearance on both sides and on the top of the EZC zone
  controller for ease of service.

### Wall Mounting

- Use the keyholes located on the back of the EZC zone controller.
- Check the solidity of the chosen support or wall (brick, concrete, or stud partition wall) on which the EZC zone controller is mounted.
- Drill holes for the upper anchors (holes with keyholes) into the support or wall, as per dimensions specified in the below table (anchors not supplied):

Table 3 - Dimensions for Drilling Holes (EZC)

| NA - Jal | Dimensions in (mm) |          |  |  |  |
|----------|--------------------|----------|--|--|--|
| Model    | D                  | E        |  |  |  |
| EZC1     | 13.2 (336)         | 13 (330) |  |  |  |
| EZC2     | 16 (408)           | 13 (330) |  |  |  |
| EZC3     | 19 (480)           | 13 (330) |  |  |  |
| EZC4     | 22 (550)           | 13 (330) |  |  |  |



- Ensure that the hole dimensions (diameter and depth) adhere to the recommendations of the chosen anchors. If required, you can install and then bolt the anchors.
- Affix two screws (not supplied) with a minimum diameter of 0.23" (6mm) to the top keyholes. Leave a clearance between the head screws and the wall to permit the mounting of the EZC zone controller.
- Hang the EZC zone controller on the two screws. Based on the size and weight of the EZC zone controller, you may need the assistance of another person.
- Tighten the screws to secure the EZC zone controller once it is positioned on the upper screws.
- Install and secure two screws (not supplied) onto the bottom screw holes of the EZC zone controller.



# **Step 3 – Mist Distribution Ramp and Nozzle Installation**

### **Spraying in Space (Standard)**

- Plan a location that is easy to access and permits an easy inspection and servicing of the nozzle.
- Do not install the ramp and nozzle where failure of the system could cause damage to the building structure or to other expensive equipment.
- Ensure that the mist is not directed and condensed on any electrical equipment.
- Construct the drain pipe in such a way that there is no water accumulation and stagnation.




Illustration 7 - Typical Installation with Rigid Nozzle Ramp



Note: The flexible HP hose must be maintained/attached and should not move when pressure is applied.



# **SKH High-Pressure Atomizer** Installation Instructions and User Manual




Illustration 8 - Typical Installation with Flexible Hose



#### Installation Instructions and User Manual

### **Spraying in Space with MDU**

- Plan a location that is easy to access and permits an easy inspection and servicing.
- Do not install the MDU where failure of the system could cause damage to the building structure or to other expensive equipment.
- Ensure that the mist is not directed and condensed on any equipment, particularly electrical equipment.
- Construct the drain pipe in such a way that there is no water accumulation and stagnation.

### Ceiling Installation

To install the MDU to the ceiling, connect two metallic suspension cables (not supplied) to the three 0.213" (5.4mm) holes found around the unit as per the following steps. Verify the strength of the cables and ensure that they are capable of supporting the weight of the MDU (15 lb [6.8 kg]) before commencing installation.

- A. Attach a Y-fit suspension cable in any two of the three support holes. Ensure that the cable is securely and appropriately affixed to the MDU.
- B. Attach a suspension cable in the remaining third hole. Ensure that the cable is securely and appropriately affixed to the MDU.
- C. Connect the MDU to the ceiling using the ends of the two suspension cables. Ensure that the unit remains in balance and that it is firmly held in place by the two metal cables. Verify that all connections are secure.




Illustration 9 - Installation of the MDU to the Ceiling



Installation Instructions and User Manual

### Connecting the MDU to the EZC Zone Station

- After completing the installation of the MDU(s) to the ceiling, connect piping from the EZC Zone Station to the MDU system using flexible hoses (not supplied), as illustrated in the following diagram.
- For systems comprised of multiple MDUs, connect each MDU in series along a flexible hose line.
- Connect each MDU to the flexible hose line using a T push-on fitting (supplied). Connect the bottom side of the T push-on fitting to the MDU using a 3/8" flexible hose with a 3/8" quick connect fitting (not supplied).
- Ensure that each MDU is separated by a radius of 10ft (3m) from any other device. Leave a distance of 20ft (6m) between two nearby MDUs.




Illustration 10 - Typical Installation of MDU to EZC



### Installation Instructions and User Manual

### **Spraying in Duct**

- Plan a location that is easy to access and permits an easy inspection and servicing of the nozzle.
- Do not install the ramp and nozzle where failure of the system could cause damage to the building structure or to other expensive equipment.
- Ensure that the mist is not directed and condensed on any electrical equipment.
- Construct the drain pipe in such a way that there is no water accumulation and stagnation.

#### Assembling the Racks



WARNING: Risk of electric shock. Ensure that you take precautions to prevent electrostatic discharge (ESD) damage.



Note: Ensure that tools such as a screwdriver, adjustable wrench, and so on are available before assembling the racks.

- A. Affix the female brackets to the male bracket using 4x 8-32 self-tapping screws and tighten securely.
- B. Affix the feet at the top and at the bottom of the racks. When attaching the feet to a female bracket, use 4x 8-32 screws with 4x 8-32 nuts. When attaching the feet to a male bracket, use 4x 8-32 self-tapping screws and tighten securely.
- C. Use 2x 8-32 screws to affix the cross angles.
- D. Affix the piping and spray nozzles with push-on fittings using an 8-32 self-tapping screw and grommets.

The following diagram describes how to affix the rack assembly within a duct:




Illustration 11 - Assembling the Racks





Ensure that the nozzles with push-on fittings are fixed at an angle of 30°, as shown in the following diagram:




Illustration 12 - Rack Assembly within a Duct



Installation Instructions and User Manual

After completing the rack assembly within the duct, connect piping from the EZC Zone Station to the appropriate rack assembly inlets, as illustrated in the following diagram:



Note: Parts of the rack assembly described in the following diagram are provided by Others/Third-party vendors and are not supplied by Neptronic.




Illustration 13 - Typical Installation – Connecting to the EZC Zone Station



Installation Instructions and User Manual

### Installing a Droplet Separator (Optional)

An optional droplet separator can be added at any time during the life of the SKH to prevent any possible carryover. If no trap is included, install a separate trap that can adequately handle the condensate load.



Note: Neptronic recommends the use of a droplet separator when the air velocity is above 600FPM (3m/sec).




Illustration 14 - Droplet Separator



# **Step 4 – Water and Drain Connections**

### Water Connections for SKH Pump Station – Overview

- Install an isolation valve (not supplied) on the water line near the evaporative module's inlet for ease of maintenance and servicing.
- Flush the water line thoroughly before connecting the feed water pipe-work to the evaporation module.




Illustration 15 - Water Connections - Pump Station



Note: Do not over tighten the hose fittings as this may damage the seals.

**Table 4 - Water Supply and Drain Connection Specifications** 

| Consideration  |                       | Models                     |             |             |               |         |  |  |
|--|-----------------------|----------------------------|-------------|-------------|---------------|---------|--|--|
| Specification  | SKH100                | SKH200                     | SKH300      | SKH600      | SKH900        | SKH1200 |  |  |
| Water overflow outlet type and size (Optional feature) |                       |                            | ½" (DN15)   | Hose barb   |               |         |  |  |
| Water supply inlet type and size                       | Fem                   | ale NPT ½" (C              | N15)        | Fem         | ale NPT ¾" (D | N20)    |  |  |
| Minimum water supply pressure                          |                       | 30 PSI (2.0 bar)           |             |             |               |         |  |  |
| Maximum water supply pressure                          |                       |                            | 70 PSI      | (4.8 bar)   |               |         |  |  |
| Minimum water supply temperature                       |                       |                            | 38°F        | (3°C)       |               |         |  |  |
| Maximum water supply temperature                       |                       |                            | 77°F        | (25°C)      |               |         |  |  |
| Water supply quality                                   | 35 ppm TDS            |                            |             |             |               |         |  |  |
| Main drain outlet type and size                        | 1/2" (DN15) Hose barb |                            |             |             |               |         |  |  |
| Pan drain outlet type and size                         |                       | 3/4" (DN20) Hydraulic tube |             |             |               |         |  |  |
| High-pressure water outlet type and size               |                       |                            | Female 3/8" | (DN10) BSPP |               |         |  |  |



# SKH High-Pressure Atomizer Installation Instructions and User Manual

#### Water Supply

- Connect the female NPT connection of the water supply inlet of the humidifier to a clean drinking water supply.
- The SKH is capable of operating with water qualities such as reverse osmosis (RO) or tap water.
- If the humidifier is connected to hard water, it results in scale build-up and clogging of the spray nozzles, resulting in frequent replacement of nozzles. Furthermore, most of the minerals contained in the water are sprayed into the air.
- If the supplied water is treated with reverse osmosis or deionization filtration, control the total dissolved solid contents in the water, as there is no need for ultra-pure water.
- Ensure that the conductivity of water is between 1.92 and 5.12 PPM (30 and 80 μS/cm) at 68°F (20°C).

#### **High-Pressure Water Outlet**

- Connect the high-pressure water outlet from the SKH pump station to the high-pressure water inlet on the EZC controller using a flexible hose (not supplied), in order to dampen vibrations.
- Use a 3/8" (DN10) flexible high-pressure nylon hose or a high-pressure hydraulic hose (not supplied). The hose must use stainless steel quick connect fittings with one male 3/8" (DN10) BSPP and one male ½" (DN8) BSPP fitting (not supplied).
- Connect the male 3/8" (DN10) BSPP fitting of the hose to the female 3/8" (DN10) BSPP fitting of the highpressure water outlet of the pump station.
- Connect the male ¼" (DN8) BSPP fitting of the hose to the female ¼" (DN8) BSPP fitting of the high-pressure water inlet of the EZC controller.



Note: Ensure that the rating of the flexible hose is appropriate for the operating pressure (1000PSI / 70 bar).

#### Water Drain

- Connect a ½" (DN15) flexible hose (not supplied) to the ½" (DN15) hose barb fitting of the main drain outlet, located on the side of the SKH pump station, and direct it to the main building open drain.
- Connect a ¾" (DN20) flexible hose (not supplied) to the ¾" (DN20) pan drain outlet tube, located below the base of the SKH pump station, and direct it to the main building open drain.



WARNING: Risk of flooding. Never connect drains to closed pipework.

#### Water Overflow (Optional Feature)

- Connect the ½" (DN15) hose barb fitting of the water overflow outlet, located on the side of the SKH pump station, to a ½" (DN15) flexible hose (not supplied).
- Do not combine the overflow and drain to a common pipe if you plan to drain the water. Install two
  independent traps for drain and overflow.
- Re-circulate the overflowing water as required by making appropriate connections.



Installation Instructions and User Manual

#### Water Connections on EZC





Illustration 16 - Water Connections on EZC (Back View)

#### High-Pressure Water Inlet from SKH Pump Station

- Connect the high-pressure water inlet on the EZC controller to the high-pressure water outlet from the SKH pump station using a flexible hose (not supplied), in order to dampen vibrations.
- Use a 3/8" (DN10) flexible high-pressure nylon hose or a high-pressure hydraulic hose (not supplied). The hose must use stainless steel quick connect fittings with one male 3/8" (DN10) BSPP and one male ¼" (DN8) BSPP fitting (not supplied).
- Connect the male ¼" (DN8) BSPP fitting of the hose to the female ¼" (DN8) BSPP fitting of the high-pressure water inlet of the EZC controller.
- Connect the male 3/8" (DN10) BSPP fitting of the hose to the female 3/8" (DN10) BSPP fitting of the highpressure water outlet of the pump station.



#### High-Pressure Water Outlet to Nozzle

- Connect the ¼" (DN8) BSPP fitting of the high-pressure water outlet from the EZC controller to the nozzle ramps, MDU(s) or nozzles.
- For in-duct spray systems, ensure that the high-pressure water line is made up of 3/8" (DN10) rigid stainless steel pipes (not supplied).
- For standard in-space spray systems, ensure that the high-pressure water line is made up of 3/8" (DN10) flexible nylon hoses or rigid stainless steel pipes (not supplied).
- For in-space spray systems with MDU(s), ensure that the high-pressure water line is made up of 3/8" (DN10) flexible nylon hoses (not supplied).

Ensure that the rating of the flexible hoses is appropriate for the operating pressure.



### **SKH High-Pressure Atomizer** Installation Instructions and User Manual

#### Water Drain

- Connect a ¼" (DN8) flexible hose (not supplied) to the ¼" (DN8) BSPP fitting of the water drain outlet, located below the EZC controller, and direct it to a main building open drain.
- If an in-duct spray system is used, connect the ½" (DN8) BSPP fitting of the water drain inlet to the nozzle rack assembly using a 3/8" (DN10) rigid stainless steel pipe with compression fittings (not supplied).
- If a standard in-space spray system is used, connect the ½" (DN8) BSPP fitting of the water drain inlet to the nozzles using a 3/8" (DN10) flexible nylon hose with quick connect fittings or a 3/8" (DN10) rigid stainless steel pipe with compression fittings (not supplied).
- If an in-space spray system with MDU is used, connect the ½" (DN8) BSPP fitting of the water drain inlet to the MDU(s) using a 3/8" (DN10) flexible nylon hose with quick connect fittings (not supplied).



WARNING: Risk of flooding. Never connect drains to closed pipework.



### Installation Instructions and User Manual

# **Step 5 – Power Supply Connections**



WARNING: All work concerned with electrical installation MUST only be performed by skilled and qualified technical personnel, such as electricians or technicians with appropriate training. The customer is responsible for ensuring their suitability.



WARNING: Risk of electric shock. Isolate all power supplies before installation and maintenance of the SKH High-Pressure Atomizer or the EZC.



You MUST externally fuse all incoming power supplies for over current protection.

Observe local codes and regulations concerning the provision of electrical installations.

The installation engineer must ensure the following:

- Use copper power conductors only.
- Ensure that the size of the power conductors is suitable for the maximum current supplied.
- Secure incoming power cables using a suitably sized cable gland.
- Secure each terminal connection with a cable ferrule.
- Do not use the SKH pump station's frame to connect to ground. The SKH pump station cabinet has a continuous or unbroken electrical ground.

### **Power Supply Connections on MDU**

When using an in-space distribution system with MDU, refer to the following specifications:

**Table 5 - MDU Power Supply Specifications** 

| Model   | Voltage (Vac) / 1ph | Current (A) | Frequency (Hz) |
|---------|---------------------|-------------|----------------|
| MDU-120 | 120                 | 1           | 60             |
| MDU-230 | 230                 | 1           | 50             |



Installation Instructions and User Manual

### **Power Supply Connections on SKH Pump Station**




Illustration 17 - Power Supply Connections on SKH Pump Station

**Table 6 - SKH Pump Station Power Supply Specifications** 

|          |             | Models      |        |        |        |        |         |  |  |  |
|----------|-------------|-------------|--------|--------|--------|--------|---------|--|--|--|
| Phase    | Voltage (V) | SKH100      | SKH200 | SKH300 | SKH600 | SKH900 | SKH1200 |  |  |  |
|          |             | Current (A) |        |        |        |        |         |  |  |  |
| 1 Phase  | 208 - 240   | 6.0         | 8.7    | N/A    | N/A    | N/A    | N/A     |  |  |  |
|          | 208 - 240   | 6.0         | 8.7    | 12.3   | 18.3   | 23.5   | 23.5    |  |  |  |
| 3 Phase  | 380 - 480   | 3.1         | 4.4    | 6.2    | 9.2    | 11.8   | 11.8    |  |  |  |
|          | 575 - 600   | 2.3         | 3.5    | 4.9    | 7.3    | 9.4    | 9.4     |  |  |  |
| Power    |             |             |        |        |        |        |         |  |  |  |
| HP<br>kW |             | 2           | 3      | 5      | 7.5    | 10     | 10      |  |  |  |
|          |             | 1.5         | 2.25   | 3.75   | 5.6    | 7.5    | 7.5     |  |  |  |



# **Power Supply Connections on Electronic Zone Controller (EZC)**




Illustration 18 - Power Supply Connections on EZC

**Table 7 - EZC Power Supply Specifications** 

| Model                 | Voltage (Vac) / 1ph | Current (A) | Frequency (Hz) |
|-----------------------|---------------------|-------------|----------------|
|                       | 120                 | 1.4         | 60             |
|                       | 208/240             | 0.7         | 60             |
| EZC1                  | 230                 | 0.7         | 50             |
| EZCI                  | 400                 | 0.4         | 50             |
|                       | 480                 | 0.4         | 60             |
|                       | 575/600             | 0.3         | 60             |
|                       | 120                 | 2.0         | 60             |
|                       | 208/240             | 1.1         | 60             |
| EZC2                  | 230                 | 1.1         | 50             |
| EZCZ                  | 400                 | 0.6         | 50             |
|                       | 480                 | 0.6         | 60             |
|                       | 575/600             | 0.4         | 60             |
|                       | 120                 | 2.7         | 60             |
|                       | 208/240             | 1.4         | 60             |
| F702                  | 230                 | 1.4         | 50             |
| EZC3                  | 400                 | 0.8         | 50             |
|                       | 480                 | 0.8         | 60             |
|                       | 575/600             | 0.5         | 60             |
|                       | 120                 | 3.4         | 60             |
|                       | 208/240             | 1.8         | 60             |
| F704                  | 230                 | 1.8         | 50             |
| EZC4                  | 400                 | 1.0         | 50             |
|                       | 480                 | 1.0         | 60             |
|                       | 575/600             | 0.7         | 60             |
|                       | 120                 | 11.4        | 60             |
| EZC MDU<br>(with MDU) | 208/240             | 10.7        | 60             |
| (WITH INDO)           | 230                 | 10.7        | 50             |



# **Step 6 – Electrical Control Connections**



WARNING: All work concerned with electrical installation MUST only be performed by skilled and qualified technical personnel, such as electricians or technicians with appropriate training. The customer is responsible for ensuring their suitability.



WARNING: Risk of electric shock. Isolate all power supplies before installation and maintenance of the SKH High-Pressure Atomizer.




Illustration 19 - SKH Controller Wiring Diagram

### **Safety Contact Connections**

- *Airflow Switch*. Wire the contact on the EZC between terminals TB10 1&3. If this contact opens, the operation of the SKH unit stops. The unit displays the Airflow Switch as 'open,' but will **not** generate an alarm.
- High Limit Humidistat. Wire the contact on the EZC between terminals TB10 2&3. If this contact opens, the operation of the SKH unit stops, and an **Alarm** will be displayed. If spraying in-space, High limit humidistat is not required, but a jumper must be installed between terminals TB10 2&3.
- Interlock. Wire the switch on the EZC between terminals TB10 3&4. If this contact opens, the operation of the SKH unit stops and an Alarm will be displayed. If Interlock is not used, install a jumper between terminals TB10 3&4.

### **On/Off Operation**

For On/Off operation, connect the On/Off contact between TB10 3&5. If this contact opens, the SKH humidifier will turn off. If this contact closes, the SKH humidifier will operate.



Installation Instructions and User Manual

### **Modulating Operation**

#### Analog – External Signal

Irrespective of the source of the control signal (BMS, room or duct humidistat, room or duct thermostat, or a combination), the external control signal should be connected on the EZC between terminals TB9 1&3. These analog inputs are configurable at step 4A "Source" and 4B "Signal" of the Controls menu (see page 43).

#### BACnet - Network

The SKH master pump station may use BACnet to communicate with the EZC zones. If the control signal is a BACnet network, use terminals TB7 1&2 to connect to an external BMS integration system. Select network control signal at step 4A "Source" of the Controls menu (see page 43). Refer to step 5I "BACnet Network" of the Configuration menu (see page 44) to set up the communication parameters.




Illustration 20 - BACnet Connection



Installation Instructions and User Manual

#### **TRLH Control**

When using a TRLH thermostat, connect the EZC controller to the TRLH as per the following diagram. For more details, consult the TRLH24-INT Thermostat Specification & Installation Instructions.




Illustration 21 - TRLH to EZC Control Connections




Installation Instructions and User Manual

### **Dry Contacts**

Two series of volt free contacts are provided on the SKH pump station master PCB:

- 1. Alarm Contacts (TB4)
- 2. Service Contacts (TB3)
- These contacts are used to switch a low voltage, ideally 24V, with a switching current of no more than 3 Amps.
- Each series has one Normally Closed contact and one Normally Open contact.
- It is recommended to use the Normally Closed contact, as this contact will open in the event of a humidifier fault.





Installation Instructions and User Manual

### **Pump Station to EZC Control Connections**

The pump station PCB must be connected to the EZC controller using a network communication cable. Terminals TB2 1&2 on the SKH pump station master PCB must be connected with terminals TB6 1&2 on the EZC controller.



It is recommended to use 24 AWG shielded twisted pair cables (Belden 9841 or equivalent).




Illustration 22 - Pump Station to EZC Control Connections (Single EZC)

For systems comprised of more than one zone, each EZC controller must be connected in a daisy chain configuration, meaning that every controller must be connected in parallel directly along the path of the main communication cable. Connect terminals TB6 1&2 of every EZC controller along the chain with terminals TB6 1&2 of the previous EZC controller. It is important to keep the same color for all the A+ wiring and a different color for all the B- wiring.



It is recommended to use 24 AWG shielded twisted pair cables (Belden 9841 or equivalent).




Illustration 23 - Pump Station to EZC Control Connections (Multiple EZCs)



Installation Instructions and User Manual

#### **Shield Wiring**

Shields from each feed of the network connection to a controller must be wired together. Special attention must be taken to ensure that the shields are well-protected (ends tapped or covered) to prevent any connection to ground that could influence the shield reference. This could create ground loops and change the reference level of the network. The shield in a daisy chain format is then grounded at one end only. Do not ground the shield at more than one location, as this may induce ground loop noise.




Illustration 24 - Pump Station to EZC Shield Wiring

### End of Line (EOL) Termination

In order to avoid reflection issues, an End of Line (EOL) must be installed at both ends of the physical network wire (the pump station PCB and the last EZC controller). Set the EOL directly on the controller. Do not install an EOL at any intermediate EZC controller on the network. Communication is achieved by using an electrical pulse signal and when no EOLs are installed, the pulse signal reflects backwards and collides with other data pulses.




Illustration 25 - Pump Station to EZC EOL Setup



# **SKH High-Pressure Atomizer** Installation Instructions and User Manual

### **EZC Controller DIP Switches**

### **DS1** (Network Options)

| ſ | Baud Rate Selection  |                         | Auto Baud Rate                 | Network Type                      |  |  |
|---|--|-------------------------|--------------------------------|-----------------------------------|--|--|
|   | 1 2  |                         | 3                              | 1                                 |  |  |
|   | 1 OFF / 2 OF<br>1 ON / 2 OF<br>1 OFF / 2 ON<br>1 ON / 2 ON | FF = 19200<br>N = 38400 | OFF = Disabled<br>ON = Enabled | OFF = BACnet MS/TP<br>ON = Modbus |  |  |

### DS2 (MAC Address)

MSTP/MAC address for communication is selectable by DIP switch using binary logic. If the device instance is not changed using program mode, it will automatically be modified according to the MAC address.

| MAC<br>Address | DS.1 = 1 | DS.2 = 2 | DS.3 = 4 | DS.4 = 8 | DS.5 = 16 | DS.6 = 32 | DS.7 = 64 | DS.8 = 128 | Default Device Instance |
|----------------|----------|----------|----------|----------|-----------|-----------|-----------|------------|-------------------------|
| 0              | OFF      | OFF      | OFF      | OFF      | OFF       | OFF       | OFF       | OFF        | 153000                  |
| 1              | ON       | OFF      | OFF      | OFF      | OFF       | OFF       | OFF       | OFF        | 153001                  |
| 2              | OFF      | ON       | OFF      | OFF      | OFF       | OFF       | OFF       | OFF        | 153002                  |
| 3              | ON       | ON       | OFF      | OFF      | OFF       | OFF       | OFF       | OFF        | 153003                  |
| 4              | OFF      | OFF      | ON       | OFF      | OFF       | OFF       | OFF       | OFF        | 153004                  |
|                |          |          |          |          |           |           |           |            |                         |
| 126            | OFF      | ON       | ON       | ON       | ON        | ON        | ON        | OFF        | 153126                  |
| 127            | ON       | ON       | ON       | ON       | ON        | ON        | ON        | OFF        | 153127                  |



Installation Instructions and User Manual

### **EZC to MDU Control Connections**

For in-space spray distribution systems using one or multiple MDUs, connect the EZC controller to the MDU(s) as per the following diagram.




Illustration 26 - EZC to MDU Control Connection



Installation Instructions and User Manual

### **Step 7 – Controller Installation and Configuration**



Illustration 27 - SKH Controller



The Power button is protected from accidental activation by a 3 second delay. **Press and hold the Power button for 3 seconds to perform the related action**.

### **Menu Overview**

When the SKH controller is in operation, the unit displays two information screens. After the Model screen is displayed for 3 seconds, the controller displays and remains on the System Info screen. Press the ▲ and ▼ buttons located on the right of the screen to manually scroll through each screen.

| Model    |            |           |                |  |  |  |
|----------|------------|-----------|----------------|--|--|--|
| Model    |            | SKH       |                |  |  |  |
| Firmware |            | 1.0       |                |  |  |  |
| Serial # |            | 14H010001 | <b>A</b>       |  |  |  |
|          |            |           | $\blacksquare$ |  |  |  |
|          |            |           |                |  |  |  |
| SD ▶     | 2015-06-02 | 15:13:23  |                |  |  |  |

The first screen indicates the model #, firmware revision installed and the controller's serial #.

The SD icon appears if the controller detects a micro SD card. Current time and date are also displayed.

| Sys                 | tem Info    |                |
|---------------------|-------------|----------------|
| Inlet water temp.   |             |                |
| Inlet Pressure      | 100.0%      |                |
| Output Press.       | 1000kg/h    | <b>A</b>       |
| VFD                 |             | $\blacksquare$ |
| In. Water Temp. Hig | gh          |                |
| In. Water Temp. Lo  | w           |                |
| Output              |             |                |
| SD ▶ 2015-06-0      | 02 15:13:23 |                |

The second screen displays information about the operation of the system.

The SD icon appears if the controller detects a micro SD card. Current time and date are also displayed.



### Installation Instructions and User Manual

### **Menu Navigation and Configuration**

- A. Press the Menu \* button.
- B. Use the ▲, ▼ buttons to select the desired main menu category and press Enter ⅃.
- C. If a password is required (see table below), enter the password and press Enter  $\ \ \ \ \ \ \ \ \ \$ . If you enter the wrong password, the SKH controller displays an "invalid password" message.

Table 8 - Passwords

| Mode/Menu     | Password | Priority |
|---------------|----------|----------|
| User          | None     | 1        |
| Status        | None     | 1        |
| Service       | 637      | 2        |
| Controls      | 757      | 3        |
| Configuration | 372      | 4        |



If a password of higher priority was already provided, individual passwords are not required. For example, if the Configuration Menu password was validated already, access to other menus such as Controls is unlocked automatically.

- D. Use the + and buttons to increase and decrease the values. Use the ▲, ▼ buttons to scroll to the next or previous menu item. The entered values are saved immediately once the changes are done.
- F. To exit completely, press the Menu \* button to exit until you return to the menu overview or after 60 seconds of inactivity, the controller will automatically return to the menu overview.




Available settings and range of selections may vary depending on current configuration. The tables in the following sections display all the possible selections. The Notes/Conditions column indicates the conditions required for the associated setting to appear.



Installation Instructions and User Manual

### Main Menu - User



Press [\*] to access the Main Menu

**Select User** 

Adjust the required settings


\*Option D only appears if an internal control mode has been selected in menu 4A) Source.

| USER          | Settings           | Default                  | Range   | Notes/Conditions  |  |
|---------------|--------------------|--------------------------|---|---|--|
|               | Time format:       | 24h                      | 12h (AM/PM) or 24h  |   |  |
|               | Actual time:       | 00:00                    | 0 to 24 hours : 00 to 59 minutes                                  |   |  |
| 1A) Clock     | Date(YY-MM-DD):    | YYYY-MM-DD               | YYYY-MM-DD  |   |  |
|               | UTC diff:          | -300 min                 | -780 to +780 min  |   |  |
|               | Daylight saving:   | Off                      | On (Enable), Off (Disable)  |   |  |
|               | Language:          | English                  | English   |   |  |
| 1B) Options   | Contrast:          | 10                       | 0 to 10   |   |  |
|               | Alarm beep:        | Off                      | On (Enable), Off (Disable)  |   |  |
|               | Key press beep:    | Off                      | On (Enable), Off (Disable)  |   |  |
|               | Temp. units:       | °C                       | °C or °F  |   |  |
| 1C) Units     | Press. units:      | kPa                      | kPa, bar, psi   |   |  |
|               | Mass flow units:   | kg/h                     | kg/h, lb/h  |   |  |
|               | Zone Select:       | 1                        | 1 to 10   | Select zone before setup.   |  |
|               | Out of service:    | Off                      | On (Enable), Off (Disable)  |   |  |
|               | Start Date:        | YYYY-MM-DD               | YYYY-MM-DD  |   |  |
|               | End Date:          | YYYY-MM-DD               | YYYY-MM-DD  | Appears if an internal control mode is selected   |  |
|               | Sched. Default:    | Off                      | Occup., Unoccup., Vacancy, Off, Null                              | in menu <b>4A) Source</b> .   |  |
|               | Prio. For Writ.    | 1                        | 1 to 16   |   |  |
|               | a) Weekly schedule | e                        |   |   |  |
| 1D) Occ.      | Zone Select:       | 1                        | 1 to 10   | Select zone before setup.   |  |
| Schedule      | Day:               | Monday                   | Monday, Tuesday, Wednesday,<br>Thursday, Friday, Saturday, Sunday |   |  |
|               | Event 1:           | Off   00:00              | Unused, Occup., Unoccup., Vacancy, Off                            | 00:00 to 23:59  |  |
|               | Event 2:           | Off   00:00              | Unused, Occup., Unoccup., Vacancy, Off                            | 00:00 to 23:59  |  |
|               | Event 3:           | Off   00:00              | Unused, Occup., Unoccup., Vacancy, Off                            | 00:00 to 23:59  |  |
|               | Event 4:           | Off   00:00              | Unused, Occup., Unoccup., Vacancy, Off                            | 00:00 to 23:59  |  |
|               | Event 5:           | Off   00:00              | Unused, Occup., Unoccup., Vacancy, Off                            | 00:00 to 23:59  |  |
|               | Event 6:           | Off   00:00              | Unused, Occup., Unoccup., Vacancy, Off                            | 00:00 to 23:59  |  |
|               | Zone Select:       | 1                        | 1 to 10   | Select zone before setup.   |  |
|               | Occupied:          | 22.0 °C or<br>**40.0 %RH | 10 to 40 °C or<br>**5.0 to 95.0 %RH                               | Appears if an internal control mode is selected in menu <b>4A) Source</b> .   |  |
| 1E) Setpoints | Unoccupied:        | 0.0 °C or<br>**0.0 %RH   | 10 to 40 °C or<br>**5.0 to 95.0 %RH                               | If "Setpoint source" setting is set to <i>Inter. stpnt</i> , Occupied setting will appear.  |  |
|               | Vacant:            | 0.0 °C or<br>**0.0 %RH   | 10 to 40 °C or<br>**5.0 to 95.0 %RH                               | If "Setpoint source" setting is set to <i>Network</i> , Occupied(ntwrk) setting will appear.  |  |
|               | Occupied(ntwrk):   | 0.0 °C or<br>**0.0 %RH   | 10 to 40 °C or<br>**5.0 to 95.0 %RH                               | **Setpoint is displayed as either temperature or<br>humidity depending on the configuration<br>selected in menu <b>4A) Source</b> . |  |



Installation Instructions and User Manual

### Main Menu - Status



Press [\*] to access the Main

Menu

Select Status

Adjust the required settings

| STATUS          | Settings           | Default                | Range (* indicates no configuration; display only) | Notes/Conditions  |
|-----------------|--------------------|------------------------|--|---|
|                 | Zone Select:       | 1                      | 1 to 10  | Select zone station to review.  |
|                 | State:             | stand-by               | *  |   |
|                 | Occupancy:         | Occup.                 | *Occup., Unoccup., Vacancy, Off                    | Appears if an internal control mode is selected in menu <b>4A) Source</b> .   |
|                 | Zone demand:       | 0.0 %                  | *  |   |
|                 | Zone Output:       | 0.0 %                  | *  |   |
|                 | Ext sensor hum:    | 0.0 %RH                | *  | Appears if the "Humidity source" setting is set to <i>Al4</i> in menu <b>4A) Source</b> .   |
|                 | Ext sensor temp:   | 0.0 °C                 | *  | Appears if the "Temp. source" setting is set to <i>Al5</i> in menu <b>4A) Source</b> .  |
|                 | TRLH Hum:          | 0.0 %RH                | *  |   |
|                 | TRLH Temp:         | 0.0 °C                 | *  |   |
|                 | Network RH:        | 0.0 %RH                | *  | Appears if the "Humidity source" setting is set to <i>Network</i> in menu <b>4A) Source</b> .   |
|                 | Network temp.:     | 0.0 °C                 | *  | Appears if the "Temp. source" setting is set to <i>Network</i> in menu <b>4A) Source</b> .  |
| 2A) Zone Status | External setpoint: | 0.0 °C or<br>**0.0 %RH | *  | Appear if the "Setpoint source" setting is se to Al3 in menu 4A) Source, when using an internal control mode.  **Setpoint is displayed as either temperature or humidity depending on the configuration selected in menu 4A) Source |
|                 | High limit Hum:    | 0.0 %RH                | *  | Appears if the "High limit src" setting has been configured in menu <b>4A) Source</b> .   |
|                 | Interlock:         | Closed                 | * (Opened or Closed)                               |   |
|                 | Air flow cutout:   | Closed                 | * (Opened or Closed)                               |   |
|                 | High Lim. cutout:  | Closed                 | * (Opened or Closed)                               |   |
|                 | Drain countdown:   | 0 s                    | *  |   |
|                 | Inact countdown:   | 0 s                    | *  |   |
|                 | Stage 1:           | Off                    | * On, Off  |   |
|                 | Stage 2:           | Off                    | * On, Off  |   |
|                 | Stage 3:           | Off                    | * On, Off  | Appear if there is more than one stage.   |
|                 | Stage 4:           | Off                    | * On, Off  |   |
|                 | Board temp:        | 0.0°C                  | *  |   |
|                 | Micro temp:        | 0.0°C                  | *  |   |
|                 | State:             | stand-by               | *  |   |
|                 | Enable VFD:        | On                     | * On, Off  |   |
|                 | Pump demand:       | 0.0 %                  | *  |   |
| 2B) Pump Status | Pump feedback:     | 0.0 %                  | *  |   |
| ,               | Inlet temp. sens:  | 0.0 °C                 | *  |   |
|                 | Inlet press. sens: | 0.0 kPa                | *  |   |
|                 | Output pressure:   | 0.0 kPa                | *  |   |
|                 | Weight duty time:  | 0 h                    | *  |   |



| STATUS              | Settings       | Default  | Range (* indicates no configuration; display only) | Notes/Conditions   |
|---------------------|----------------|----------|--|--|
|                     | Duty time:     | 0 h      | *  |  |
|                     | Drain valve:   | Closed   | *  |  |
|                     | System         |          |  |  |
|                     | Reset Alarms:  | No       | Yes or No  |  |
| 2C) Alarm Command   | Pump           |          |  |  |
|                     | Reset Alarms:  | No       | Yes or No  |  |
|                     | Zone Select:   | 1        | 1 to 10  | Select zone before setup.  |
|                     | Reset Alarms:  | No       | Yes or No  |  |
|                     | Zone Select:   | 1        | 1 to 10  | Select zone station to review.   |
|                     | AI3:           | 0 mV     | * (mV)   | Appears if the "Control mode" setting is set to Ext. on A/3, or set to an internal mode with the "Setpoint source" setting set to A/3 in menu <b>4A)</b> Source. |
|                     | Al4:           | 0 mV     | * (mV)   | Appears if the "Humidity source" setting is set to <i>Al4</i> in menu <b>4A) Source</b> .  |
|                     | Al5:           | 0 mV     | * (mV)   | Appears if the "Temp. source" setting is set to Al5 in menu <b>4A) Source</b> .  |
|                     | AI6:           | 0 mV     | * (mV)   | Appears if the "High limit src" setting is set to Al6 in menu <b>4A) Source</b> .  |
|                     | DI1:           | Closed   | * (Opened or Closed)                               | Digital Input 1  |
|                     | DI2:           | Closed   | * (Opened or Closed)                               | Digital Input 2  |
|                     | DI3:           | Closed   | * (Opened or Closed)                               | Digital Input 3  |
|                     | DI4:           | Closed   | * (Opened or Closed)                               | Digital Input 4  |
| 2D)                 | Fan Low:       | Off      | * On, Off  | Only appears depending on system   |
| Zone Board IO       | Fan Med:       | Off      | * On, Off  | configuration.   |
|                     | Fan High:      | Off      | * On, Off  |  |
|                     | AO1:           | Off      | * On, Off  | Analog Output 1  |
|                     | DO1:           | Off      | * On, Off  | Digital Output 1 (Only appears depending on configuration.   |
|                     | DO2:           | Off      | * On, Off  | Digital Output 2 (Only appears depending on configuration.)  |
|                     | DO3:           | Off      | * On, Off  | Digital Output 3 (Only appears depending on configuration.)  |
|                     | DO4:           | Off      | * On, Off  | Digital Output 4 (Only appears depending on configuration.)  |
|                     | TO1:           | Off      | * On, Off  | TRIAC 1  |
|                     | TO2:           | Off      | * On, Off  | TRIAC 2  |
|                     | TO3:           | Off      | * On, Off  | TRIAC 3 (Only appears depending on configuration.)   |
|                     | TO4:           | Off      | * On, Off  | TRIAC 4 (Only appears depending on configuration.  |
|                     | AI5:           | 0 mV     | * (mV)   | Analog Input 5   |
|                     | Al6:           | 0 mV     | * (mV)   | Analog Input 6   |
|                     | AI7:           | 0 mV     | * (mV)   | Analog Input 7   |
| 2E)                 | Al8:           | 0 mV     | * (mV)   | Analog Input 8   |
| Pump Board IO       | DI1:           | Closed   | * (Opened or Closed)                               | Digital Input 1  |
|                     | AO1:           | 0 mV     | * (mV)   | Analog Output 1  |
|                     | K1:            | Off      | * On, Off  |  |
|                     | K2:            | Off      | * On, Off  |  |
|                     | K3:            | Off      | * On, Off  |  |
|                     | System         | 00000000 | *  |  |
|                     | Alarm:         | 00000000 | *  |  |
| OE) Troubleshortor  | Latched Alarm: | 00000000 | *  | 1  |
| 2F) Troubleshooting | Status:        | 00000000 | *  |  |
|                     | Options:       | 00000000 |  |  |
|                     | Pump           |          |  |  |

Page | 40 www.neptronic.com




| STATUS          | Settings                | Default          | Range (* indicates no configuration; display only) | Notes/Conditions                                     |  |  |
|-----------------|-------------------------|------------------|--|--|--|--|
|                 | Latched Alarm:          | 00000000         | *  |  |  |  |
|                 | Status:                 | 00000000         | *  |  |  |  |
|                 | Options:                | 00000000         | *  |  |  |  |
|                 | Comm Status:            | 00000000         | *  |  |  |  |
|                 | Zone Select:            | 1                | 1 to 10  | Select zone station to review.                       |  |  |
|                 | Alarm:                  | 00000000         | *  |  |  |  |
|                 | Latched Alarm:          | 00000000         | *  |  |  |  |
|                 | Status:                 | 00000000         | *  |  |  |  |
|                 | Options:                | 00000000         | *  |  |  |  |
|                 | Comm Status:            | 00000000         | *  |  |  |  |
|                 | a) System Alarms        | a) System Alarms |  |  |  |  |
|                 | YYYY-MM-DD   event name |                  |  |  |  |  |
|                 | YYYY-MM-DD   event name |                  |  | Displays the last three alarms of the system.        |  |  |
|                 | YYYY-MM-DD   ev         | ent name         |  |  |  |  |
|                 | b) Zone Alarms          | b) Zone Alarms   |  |  |  |  |
|                 | Zone Select:            | 1                | 1 to 10  | Select zone station to review.                       |  |  |
|                 | YYYY-MM-DD   ev         | ent name         |  |  |  |  |
|                 | YYYY-MM-DD   ev         | ent name         |  | Displays the last three alarms of the selected zone. |  |  |
| 2G) History log | YYYY-MM-DD   ev         | ent name         |  | Selected zone.                                       |  |  |
|                 | c) Pump Alarms          |                  |  | ,  |  |  |
|                 | YYYY-MM-DD   ev         | ent name         |  |  |  |  |
|                 | YYYY-MM-DD   ev         | ent name         |  | Displays the last three alarms of the pump.          |  |  |
|                 | YYYY-MM-DD   ev         | ent name         |  |  |  |  |
|                 |                         |                  | '  | -  |  |  |
|                 | Trend # days:           | 7 days           | 7-21 days  |  |  |  |
|                 | Trend interval:         | 5 min            | 1-30 min   |  |  |  |
|                 | Events of last:         | 3 months         | 1-6 months   |  |  |  |

Page | 41 www.neptronic.com



Installation Instructions and User Manual


### Main Menu - Service



| SERVICE              | Settings           | Default    | Range (* indicates no configuration; display only) | Notes/Conditions  |
|----------------------|--------------------|------------|--|---|
|                      | System             |            |  |   |
|                      | UV lamp due on:    | YYYY-MM-DD | *  | Displays the date on which the UV Lamp will have to be replaced.  |
|                      |                    |            |  | Appears if using an UV lamp.  |
|                      | Last UV lamp:      | YYYY-MM-DD | *  | Displays last date on which the "UV lamp changed?" was set to Yes.  |
|                      |                    |            |  | Appears if using an UV lamp.  |
|                      | UV lamp changed?   | No         | * Yes or No  | If the UV lamp has been changed, set this value to Yes to reset the "UV lamp due on".                           |
|                      | Pump               |            |  |   |
|                      | Silv. ion due on:  | YYYY-MM-DD | *  | Displays the date on which the Silver Ion cartridge will have to be replaced.                                   |
| 3A) Services         | Last silver ion:   | YYYY-MM-DD | *  | Displays the date on which the "Silv. ion changed?" was set to Yes.   |
|                      | Silv. ion changed? | No         | * Yes or No  | If the Silver Ion cartridge is changed, set this value to Yes to reset the "Last silver ion" date.              |
|                      | Zone Select:       | 1          | 1 to 10  | Select zone before setup.   |
|                      | Runtime Stage1:    | 0 h        | *  |   |
|                      | Reset Runtime:     | No         | Yes or No  |   |
|                      | Runtime Stage2:    | 0 h        | *  |   |
|                      | Reset Runtime:     | No         | Yes or No  |   |
|                      | Runtime Stage3:    | 0 h        | *  | Appear if there is more than one stage  |
|                      | Reset Runtime:     | No         | Yes or No  | Appear if there is more than one stage.   |
|                      | Runtime Stage4:    | 0 h        | *  |   |
|                      | Reset Runtime:     | No         | Yes or No  |   |
|                      | Sim. mode:         | Off        | On, Off  |   |
|                      | Duration:          | 5 min      | 5 to 60 min  |   |
|                      | Time Remaining:    | 0 s        | *  |   |
| 3B) Simulation       | Zone Select:       | All        | 1 to 10 or All                                     |   |
| Mode                 | Zone demand:       | 0 %        | 0 to 100 %   |   |
|                      | Pump               |            |  |   |
|                      | Pump override:     | Off        | On, Off  |   |
|                      | Pump demand:       | 0 %        | 0 to 100 %   |   |
|                      | Man. Prime Start:  | Off        | Off or Start                                       | Set to Start to start the drain sequence.   |
| 3C) Drain<br>Command | Man. Prime Stop:   | Off        | Off or Stop  | Set to <i>Stop</i> to stop the drain sequence.  Appears after "Man. Prime Start" has been set to <i>Start</i> . |



### Main Menu - Controls




| CONTROLS       | Settings           | Default                | Range  | Notes/Conditions  |
|----------------|--------------------|------------------------|--|---|
|                | Zone Select:       | 1                      | 1 to 10  | Select zone before setup.   |
|                | Control mode:      | Ext. on Al3            | Ext. on Al3 Int. in RH Int. in temp Int. Altern. Network | External control mode using Analog Input 3 (Al3). Internal control mode using Thermostat humidity. Internal control mode using Thermostat temperature.  Network option only applicable for BACnet models. |
| 4A) Source     | Setpoint source:   | Al3                    | Al3, Inter. stpnt, Network                               | Appears if an internal control mode is selected.  Network option only applicable for BACnet models.   |
|                | Humidity source:   | Al4                    | AI4, TRLH, Network, None                                 | Network option only applicable for BACnet models.   |
|                | Temp. source:      | AI5                    | Al5, TRLH, Network, None                                 | Network option only applicable for BACnet models.   |
|                | High limit src:    | Al6                    | Al6, Network, None                                       | Network option only applicable for BACnet models.   |
|                | Zone Select:       | 1                      | 1 to 10  | Select zone before setup.   |
|                | Al3 signal:        | 0-10 Vdc               | 0-10Vdc, 2-10Vdc   | Appears if the "Control mode" setting is set to Ext. on Al3, or set to an internal mode with the "Setpoint source" setting set to Al3, in menu 4A) Source.  |
| 4B) Signal     | Al4 signal:        | 0-10 Vdc               | 0-10Vdc, 2-10Vdc   | Appears if the "Humidity source" setting is set to Al4 in menu 4A) Source.  |
|                | Al5 signal:        | 0-10 Vdc               | 0-10Vdc, 2-10Vdc   | Appears if the "Temp. source" setting is set to AI5 in menu <b>4A) Source</b> .   |
|                | Al6 signal:        | 0-10 Vdc               | 0-10Vdc, 2-10Vdc   | Appears if the "High limit src" setting is set to Al6 in menu 4A) Source  |
|                | Feedback signal:   | 0-10 Vdc               | 0-10Vdc, 2-10Vdc   |   |
|                | Zone Select:       | 1                      | 1 to 10  | Select zone before setup.   |
|                | Al3 setpoint min:  | 0.0 °C or<br>**0.0 %RH | 10.0 to max °C or **5.0 to max %RH                       | Appear if the "Setpoint source" setting is set to A/3 in menu 4A) Source, when using an internal control  |
|                | Al3 setpoint max:  | 0.0 °C or<br>**0.0 %RH | Min to 40.0°C or<br>**Min to 95.0%RH                     | mode.   |
|                | Al3 setpnt offset: | 0.0 °C or<br>**0.0 %RH |  | **Setpoint is displayed as either temperature or humidity depending on the configuration selected in menu <b>4A) Source</b> .   |
|                | Al4 RH min:        | 0.0%RH                 | 5.0 to max %RH   |   |
| 4C) Ext Sensor | Al4 RH max:        | 0.0%RH                 | Min to 95.0%RH   | Appear if the "Humidity source" setting is set to Al4 in menu 4A) Source.   |
|                | Al4 RH offset:     | 0.0%RH                 |  | menu 4A) Source.  |
|                | Al5 Temp. min:     | 0.0°C                  | 10.0 to max °C   | N   |
|                | Al5 Temp. max:     | 0.0°C                  | Min to 40.0°C  | Appear if the "Temp. source" setting is set to Al5 in menu <b>4A) Source</b> .  |
|                | Al5 Temp. offset:  | 0.0°C                  |  | monu <del>17, Jource</del> .  |
|                | Al6 RH min:        | 0.0%RH                 |  |   |
|                | Al6 RH max:        | 0.0%RH                 |  | Appear if the "High limit src" setting is set to AI6 in menu 4A) Source.  |
|                | Al6 RH offset:     | 0.0%RH                 |  | mond 479 oodioo.  |



Installation Instructions and User Manual

### Main Menu - Configuration



Adjust the required settings

<sup>\*</sup>Option J only appears when a micro SD card containing a new firmware version is inserted.

| CONFIGURATION     | Settings           | Default                  | Range                               | Notes/Conditions  |
|-------------------|--------------------|--------------------------|-------------------------------------|---|
| FA) Zama Ctata    | Zone Select:       | 1                        | 1 to 10                             | Select zone before setup.   |
| 5A) Zone State    | Operation          | On                       | On, Off                             |   |
|                   | Zone Select:       | 1                        | 1 to 10                             | Select zone before setup.   |
|                   | Auto PID:          | On                       | On, Off                             |   |
| 5B) Control       | Output Limit:      | 100 %                    | 0 to 100 %                          |   |
|                   | Stage on thresh:   | 50 %                     | 0 to 100 %                          | Appears if there is no modulating stage.  |
|                   | Stage off thresh:  | 45 %                     | 0 to 100 %                          | Appears if there is no modulating stage.  |
|                   | Zone Select:       | 1                        | 1 to 10                             | Select zone before setup.   |
|                   | Setpoint:          | 80.0 %RH                 | 10 to 90 %RH                        | Appear if the "High limit src" setting has been   |
| FO) Himb Limit    | High Lim. cutout:  | 90.0 %RH                 | 50 to 95 %RH                        | configured in menu <b>4A) Source</b> .  |
| 5C) High Limit    | Prop. band RH:     | 5.0 %RH                  | 1.0 to 20.0 %RH                     |   |
|                   | Integral Time:     | 60 s                     | 0 to 600 sec                        | Proportional High limit humidity control.   |
|                   | Derivative Time:   | 0.0 s                    | 0.0 to 60.0 sec                     | Not applicable for In-Space application.  |
|                   | Zone Select:       | 1                        | 1 to 10                             | Select zone before setup.   |
|                   | Occ. setpoint min: | 10.0 °C or<br>**5.0 %RH  | 10.0 to max °C or **5.0 to max %RH  | Appear if an internal control mode is selected in menu <b>4A) Source</b> .  |
|                   | Occ. setpoint max: | 40.0 °C or<br>**95.0 %RH | Min to 40.0 °C or **Min to 95.0 %RH | **Setpoint is displayed as either temperature or<br>humidity depending on the configuration selected in<br>menu <b>4A) Source</b> . |
| 5D) Zone TRLH     | Hum sens. offset:  | 0.0 %RH                  | -10.0 to 10.0 %RH                   |   |
|                   | T sens. offset:    | 0.0 °C                   | -10.0 to 10.0 °C                    |   |
|                   | Display Time:      | Off                      | On, Off                             |   |
|                   | Setpnt. Lock:      | Off                      | On, Off                             |   |
|                   | On/Off Lock:       | Off                      | On, Off                             |   |
|                   | Time format:       | 24h                      | 12h, 24h                            |   |
|                   | Inlet temp. sens:  | 0.0 °C                   | * (sensor reading only)             |   |
|                   | offset:            | 0.0 °C                   | -10.0 to 10.0 °C                    |   |
| 5E) Pump Offset   | Inlet press. sens: | 0 kPa                    | * (sensor reading only)             |   |
| 3E) Fullip Oliset | offset:            | 0 kPa                    | -500 to 500 kPa                     |   |
|                   | Output pressure:   | 0 kPa                    | * (sensor reading only)             |   |
|                   | offset:            | 0 kPa                    | -500 to 500 kPa                     |   |
|                   | System             |                          |                                     |   |
|                   | Inact delay:       | 4 h                      | 4 to 72 h                           | Maximum allowable time of inactivity for the water inlet.   |
|                   | Inact drain time:  | 1 min                    | 1 to 255 min                        | Regulates water line drain time in the event that the Inlet Inactivity delay is attained.   |
| 5F) Delay         | Pump               |                          |                                     |   |
|                   | Inact delay:       | 4 h                      | 4 to 72 h                           |   |
|                   | Inact drain time:  | 1 s                      | 1 to 255 s                          |   |
|                   | Zone Select:       | 1                        | 1 to 10                             | Select zone before setup.   |
|                   | Fan control:       | Off                      | On, Off                             |   |



| CONFIGURATION          | Settings                | Default | Range                      | Notes/Conditions                                     |
|------------------------|-------------------------|---------|----------------------------|--|
|                        | Fan on delay:           | 1 s     | 1 to 255 s                 | Appears if the "Fan control" setting is set to On.   |
|                        | Fan off delay:          | 1 s     | 1 to 255 s                 | Appears if the "Fan control" setting is set to On.   |
|                        | Inact delay:            | 4 h     | 4 to 72 h                  |  |
|                        | Inact drain time:       | 1 s     | 1 to 255 s                 |  |
| 5G) Module<br>Presence | Zone 1<br>to<br>Zone 10 | Off/On  | On, Off                    |  |
| 5H) TRLH               | Zone Select:            | 1       | 1 to 10                    | Select zone before setup.                            |
| Presence               | Zone TRLH:              | Off/On  | On, Off                    |  |
|                        | System                  |         |                            |  |
|                        | MAC Address:            | 000     | 0 to 254                   |  |
|                        | Fallback Timeout:       | 00000   | 0 to 65534                 |  |
|                        | Device Instance:        | 0153000 | 0 to 4194302               | Available with BACnet models only.                   |
| 5I) BACnet             | Auto Baud Rate:         | On      | On (Enable), Off (Disable) |  |
|                        | Baud Rate:              | 9600    | 9.6k, 19.2k, 38.4k, 76.8k  |  |
|                        | Zone Select:            | 1       | 1 to 10                    | Select zone before setup.                            |
|                        | Device Instance:        | 0153000 | 0 to 4194302               | Assailable with DA Ocetore delegate                  |
|                        | Network Number:         | 15300   |                            | Available with BACnet models only.                   |
|                        | Modules From To         | Update? |                            |  |
|                        | Uploading pumps         | 0 %     | 0 to 100% update progress  |  |
|                        | Uploading zones         | 0 %     | 0 to 100% update progress  |  |
| 5J) Firmware<br>Update | Pump                    | No      | Yes or No                  | Appears if a micro SD card containing a new firmware |
|                        | Zone 1<br>To<br>Zone 10 | No      | Yes or No                  | version is inserted.                                 |
|                        | System x.xx             | No      | Yes or No                  |  |

### **Firmware Update**

The firmware update function is available when the unit detects a new firmware version on the micro SD card and the "Firmware upgrade available" message appears.



Install the firmware files in a folder named "SKH\_fw\_pack" in the root of the micro SD card.

- 1. Press the Menu \* button.
- 2. Use the ▲, ▼ buttons to select "5) Configuration" and press Enter ↓.
- 3. Enter the Configuration password [372]. Use the + and buttons to increase and decrease the numbers, use the ▲, ▼ buttons to change a digit, and then press Enter 

  to validate the password.
- 4. Use the ▲, ▼ buttons to select "5J) Firmware Upgrade" and press Enter ↓.
- 5. Start by updating the Slave pump firmware. To update, change the value from No to Yes.
- 6. The upgrade process can take a few minutes, and the unit will be offline for 60 seconds during the upgrade.



### **List of Alarms**

| Display                          | Origin      | Description   | Alarm Reset |
|----------------------------------|-------------|---|-------------|
| High limit cutout                | Zone        | Indicates that the high limit item is open. Verify that the signal from the high limit (duct) sensor is present at the SKH controller's input on the PCB (see schematic).   | Automatic   |
| Air flow cutout                  | Zone        | Indicates that the airflow sensor is open. Verify that the signal from the airflow sensor is present at the SKH controller's input on the PCB (see schematic).  | Automatic   |
| Interlock cutout                 | Zone        | Indicates that the interlock and the cut-out circuitry are open.  Verify that the signal from the interlock contact is present at the SKH controller's input on the PCB (see schematic).  | Automatic   |
| Board temperature failure        | Zone        | EFC PCB temperature is above the maximum temperature.   | Automatic   |
| TRL timeout                      | Zone        | Communication delay is too long between EZC and TRL.  | Automatic   |
| Network timeout                  | Zone        | Communication delay is too long.  | Automatic   |
| Invalid config                   | Zone        | Communication configuration is incorrect.   | Automatic   |
| External humidity failure        | Zone        | Humidity signal is absent or incorrect.   | Automatic   |
| External temperature failure     | Zone        | Temperature signal is absent or incorrect.  | Automatic   |
| High Limit humidity failure      | Zone        | High limit humidity signal is absent or incorrect.  | Automatic   |
| TRL humidity failure             | Zone        | TRL humidity signal is absent or incorrect.   | Automatic   |
| TRL temperature failure          | Zone        | TRL temperature signal is absent or incorrect.  | Automatic   |
| Water inlet temperature failure  | Pump        | Water inlet temperature sensor is absent or incorrect.  | Automatic   |
| Water inlet pressure failure     | Pump        | Water inlet pressure sensor is absent or incorrect.   | Automatic   |
| Pump output pressure failure     | Pump        | High-Pressure sensor is absent or incorrect.  | Automatic   |
| VFD failure                      | Pump        | VFD is out of operation.  | Automatic   |
| Water inlet temperature too high | Pump        | Water inlet temperature is above the maximum temperature.   | Automatic   |
| Water inlet temperature too low  | Pump        | Water inlet temperature is below the minimum temperature.   | Automatic   |
| Water inlet pressure too low     | Pump        | Water inlet pressure is below the minimum pressure.   | Automatic   |
| Water inlet pressure too high    | Pump        | Water inlet pressure is above the maximum pressure.   | Automatic   |
| Pump output pressure too low     | Pump        | High-Pressure is below the minimum pressure.  | Automatic   |
| Pump output pressure too high    | Pump        | High-Pressure is above the maximum pressure.  | Automatic   |
| Cooling Timeout                  | Pump        | Drain valve opens.  | Automatic   |
| Drain fault                      | Pump        | Drain operation is out of order.  | Automatic   |
| Oper Temp High                   | Pump        | Pump operating temperatures is too high.  | Automatic   |
| Service alarm                    | Pump        | Pump requires servicing.  | Automatic   |
| Pressure Timeout                 | Pump        | Communication delay is too long.  | Automatic   |
| Cooling Timeout                  | Pump        | Communication delay is too long.  | Automatic   |
| Invalid configuration            | Pump        | Configuration is invalid.   | Automatic   |
| Service warning                  | System pump | System will require service soon.   | Manual      |
| Service alarm                    | System pump | System requires service.  | Manual      |
|                                  | 1 .         | Our and the state of the state | At.a        |
| Pump timeout                     | System pump | Communication delay is too long.  | Automatic   |



Installation Instructions and User Manual

### **Start-Up Procedure**

Once the installation is complete, follow this start-up procedure in order to ensure that the SKH High-Pressure Atomizer is ready for normal operation. We strictly recommend following this procedure in order to avoid any anomaly resulting from inaccurate installation of the components.



Initial verification and start-up must be carried out by suitably qualified personnel.

### **Initial Verification**

| Clearance  | 1. | Ensure that the humidifier cabinet and the EZC controller are installed in a location where they can be serviced correctly.  |  |
|------------|----|--|--|
|            | 2. | Ensure that the pump station is installed in a temperature controlled environment of less than 86°F (30°C). Verify that the pump station is fixed securely to the ground and that it remains stable. |  |
| Mechanical | 3. | Ensure that the EZC controller is installed in a temperature controlled environment of less than 86°F (30°C). Verify that the EZC controller is fixed securely to a support or wall.                 |  |
|            | 4. | If an in-duct spray system is used, ensure that the nozzle rack assembly is correctly installed within the AHU.  |  |
|            | 5. | If an MDU is used for in-space spray distribution, ensure that it is correctly installed and secured onto the ceiling.   |  |
|            | 6. | Verify that the pump station water connections are installed properly:   |  |
|            |    | a) Ensure that water is supplied to the humidifier and that an isolation valve is installed on the water line. With the water isolation valve turned on, verify that there are no apparent leaks.    |  |
|            |    | b) Ensure that the high-pressure water outlet of the pump station is connected properly to the high-pressure water inlet of the EZC controller.  |  |
|            |    | c) Ensure that the main drain and pan drain outlets are properly connected to flexible hoses and that they are directed towards an open drain. Verify that the water drainage is not obstructed.     |  |
|            |    | d) If the humidifier has the optional water overflow outlet feature, ensure that it is connected properly to a flexible hose.  |  |
| Hydraulic  | 7. | Verify that the EZC controller water connections are installed properly:   |  |
| Tryuraunc  |    | a) Ensure that the high-pressure water inlet of the EZC controller is connected properly to the high-pressure water outlet of the pump station.  |  |
|            |    | b) Ensure that the high-pressure water outlet of the EZC controller is connected properly to the nozzle ramps, MDU(s) or nozzles.  |  |
|            |    | c) Ensure that the water drain inlet is properly connected to the nozzle ramps, MDU(s) or nozzles.   |  |
|            |    | d) Ensure that the water drain outlet is properly connected to a flexible hose and that it is directed towards an open drain. Verify that the water drainage is not obstructed.                      |  |
|            | 8. | Verify that the zone hydraulic connections are installed properly:   |  |
|            |    | a) If an in-duct spray system is used, ensure that all nozzle ramps are  |  |



|            |     | b) If a standard in-space spray distribution system is used, ensure that all nozzles within the ramp have been connected in series and that they are properly secured.  |  |
|------------|-----|---|--|
|            |     | c) If an in-space spray distribution system with MDU(s) is used, ensure that all MDUs are connected in series and that they are properly secured.   |  |
| Electrical | 9.  | Verify that the power supply (voltage) conforms to the appliance name plate on the side of the humidifier.  |  |
| Electrical | 10. | Confirm that 24Vac is present between tab 1&2 of terminal block TB11 on the EZC controller.   |  |
|            | 11. | Ensure that the communication cable between the pump station PCB and the EZC controller is properly installed and connected. For multi-zone systems, ensure that all EZC controllers are connected in a proper daisy chain format. Verify that shield wiring and EOL termination has been done correctly. |  |
|            | 12. | Ensure that the Airflow switch is properly installed and connected to the EZC controller. If an Airflow switch is not used, verify that a jumper is connected between terminals TB10 1&3.   |  |
|            | 13. | Ensure that the High limit duct humidistat is properly installed and connected to the EZC controller. Verify that the setpoint is properly adjusted. If a High limit duct humidistat is not used, verify that a jumper is connected between terminals TB10 2&3.   |  |
| Controls   | 14. | Ensure that the Interlock is properly connected to the EZC controller. If Interlock is not used, verify that a jumper is connected between terminals TB10 3&4.  |  |
|            | 15. | If a room or duct humidistat is used, verify that it is fixed securely to the wall or duct respectively and ensure that it is properly connected to the EZC controller. Verify that the setpoints are properly adjusted.  |  |
|            | 16. | If a TRLH thermostat is used, verify that it is fixed securely to a support or wall located within the desired zone and ensure that it is properly connected to the EZC controller. Verify that the setpoints are properly adjusted.  |  |
|            | 17. | Turn the power on using the circuit breaker disconnect switch.  |  |
|            | 18. | Confirm the control set-up of the humidifier by accessing the <b>4A) Source</b> option, located in the <b>Controls</b> menu. If a password is required, enter <b>757</b> .  |  |
|            | 19. | Confirm that the type of signal (0-10Vdc or 2-10Vdc) of each analog input corresponds to the type set by accessing the <b>4B) Signal</b> option, located in the <b>Controls</b> menu.   |  |

Page | 48 www.neptronic.com



### **Start-Up**

|          | 1. | Pro | oceed to start-up the humidifier, as follows:  |  |
|----------|----|-----|--|--|
|          |    | a)  | Turn on the water supply valve that is connected to the humidifier and verify that water is flowing directly to the water supply inlet of the pump station. Ensure that the water isolation valve is turned off.   |  |
|          |    | b)  | Remove the access panel located on the left side of the front of the humidifier cabinet, in order to gain access to the high-pressure pump.  |  |
|          |    | c)  | Loosen the 2 Allen screws located on the top and the bottom of the pump.   |  |
|          |    | d)  | Press the Menu button * to access the Main Menu screen. Navigate to the <b>Service</b> menu and enter the password <b>637</b> (if required). Then, select the <b>C) Drain Command</b> option.  |  |
|          |    | e)  | Set the value of the <b>Man. Prime Start</b> setting to <b>Start</b> , in order to start the drain sequence. The pump will then start draining.  |  |
|          |    | f)  | After 3 minutes have passed and the air from the pump has drained, retighten the 2 Allen screws located on the top and the bottom of the pump.   |  |
|          |    | g)  | Set the value of the <b>Man. Prime Stop</b> setting to <b>Stop</b> , in order to stop the drain sequence.  |  |
|          |    | h)  | In order to drain the air from the zone(s) and run a zone test, press the Menu button * to return to the <b>Service</b> menu screen. Then, navigate to and select the <b>B) Simulation Mode</b> option.  |  |
|          |    | i)  | Set the value of the <b>Pump demand</b> setting to <b>30%</b> .  |  |
| Start-up |    | j)  | Select the appropriate zone(s) using the <b>Zone Select</b> setting (1, 210 or <b>All</b> ) and set the value of the <b>Zone demand</b> setting to 100% for each zone that will be used.   |  |
|          |    | k)  | Set the value of the <b>Duration</b> setting to <b>10 min</b> .  |  |
|          |    | l)  | Once steps (i) to (k) have been completed, set the value of the <b>Sim. Mode</b> setting to <b>On</b> .  |  |
|          |    | m)  | After 3 minutes have passed and the air from the zone(s) has drained, slowly increase the value of the <b>Pump demand</b> setting until a value of 1000psi is displayed on the high-pressure manometer located on the front of the unit.   |  |
|          |    |     | The state of the s |  |
|          |    | n)  | Verify that all nozzles or MDUs within the zone(s) are spraying correctly and that the pressure is at 1000psi. Then, set the value of the <b>Sim. Mode</b> setting to <b>Off</b> and press the Menu button * to return to the Main Menu screen.  |  |
|          |    | o)  | Turn on the humidifier by pressing and holding the Power button of seconds. Verify that the Power Display LED light is turned on.  |  |
|          |    | p)  | Verify that there is a humidity demand displayed on the LCD screen. If there is a humidity demand, the pump station will begin pumping water to the zones and each configured zone will be activated.  |  |
|          |    | q)  | Observe the pump station and each zone for water leaks.  |  |



| Safety test | <ol><li>Check the location of the Airflow switch in the system and its operati<br/>stopping the fan. With no air movement in the air duct, the humidifier s<br/>automatically stop.</li></ol> |   |  |
|-------------|---|---|--|
| ;           | 3.  | Reset the Airflow switch if needed.               |  |
| End         | 4.  | The humidifier is now ready for normal operation. |  |

Page | 50 www.neptronic.com



Installation Instructions and User Manual

## **Servicing and Maintenance**



This humidifier must be installed, operated, and maintained by suitably qualified personnel and in accordance with this manual.

### **Preventative Maintenance**

| Component                        | How Often is<br>Maintenance Required  | Maintenance Steps  |  |  |
|----------------------------------|---|--|--|--|
| Pressure manometers              |   | - Inspect the high pressure and low pressure manometers in front of the unit and verify that the pressure is the same as the ones indicated under the <i>Inlet press. sens</i> and <i>Output pressure</i> setting in the menu <b>2B) Pump Status</b> .  - If the pressure is not the same, replace the high pressure or low pressure manometer.  |  |  |
| Hydraulic pipes                  | Every 2000 hours  | - With the unit turned on, check for leaks coming from the water supply inlet, high-pressure outlet and zone distribution piping If a leak is observed, replace the leaking pipes or fittings.   |  |  |
| Nozzles                          |   | <ul> <li>With the unit turned on, verify whether the nozzles are blocked during normal operation, or whether there is scale accumulation.</li> <li>If there is presence of scale, replace the nozzles.</li> </ul>  |  |  |
| MDU fan<br>(only for MDU option) |   | <ul> <li>With the unit turned on, verify whether the MDU fan is operating correctly and without any problems.</li> <li>Replace the motor fan is faulty operation is observed.</li> </ul>   |  |  |
| Droplet separator (option)       | If operated with regular tap water, every 2500 hours.     If operated with treated water, every 5000 hours. | <ul> <li>Verify that the droplet separator is not being obstructed by scale.</li> <li>If there is scale, proceed to de-scale the droplet separator as per the steps described in the De-scaling the Droplet Separator section on page 52.</li> </ul>   |  |  |
| Danfoss PAHT pump                | Every 8000 hours  | Verifying the conditions of the pump:  - Measure the noise level of the pump while the unit is operating. Ensure that it is below 76db.  Disassembling and inspecting the pump:  - Remove the pump from the pump station by disconnecting the four screws that secure the pump to the station and by disconnecting the hydraulic hoses.  - Disassemble the pump (refer to the Danfoss PAH/PAHT/PAHT G 10-12.5 Disassembling and assembling service guide for more details).  - If the measured noise level of the pump was found to be higher than 76db, ensure that this is not due to any malfunctioning parts.  - Replace any damaged or worn parts as necessary.  - Reassemble the pump (refer to the Danfoss PAH/PAHT/PAHT G 10-12.5 Disassembling and assembling service guide for more details) and re-attach it to the pump station.  Restarting the unit:  - Follow the steps outlined in the Start-Up section on page 49 to restart the humidifier and ensure that it is operating correctly before resuming normal operation. |  |  |



Installation Instructions and User Manual

### **Standard Maintenance**

| Component                            | How Often is<br>Maintenance Required                       | Maintenance Steps   |
|--------------------------------------|--|---|
| Pre-filter and silver ion cartridges | Every 1500 hours ( <i>Service</i> alarm will be displayed) | <ul> <li>Replace the pre-filter and silver ion cartridges.</li> <li>Modify the value of the Silv. ion changed? setting to Yes in the menu 3A) Services, in order to reset the servicing date for the pre-filter and silver ion cartridges.</li> </ul> |
| UV lamp (option)                     |  | - Replace the UV lamp Modify the value of the UV lamp changed? setting to Yes in the menu <b>3A) Services</b> , in order to reset the servicing date for the UV lamp.   |

### **De-scaling the Droplet Separator**

#### Step 1 - Preparation

- Refer to the manufacturer's recommendations for concentrations to apply and the method of preparation of the solution. When using phosphoric acid, do not exceed a concentration of 1 volume of acid for 10 parts water.
- Ensure that the air system (central air or ventilation system) is stopped.
- Ensure that the SKH is stopped.



CAUTION: When working with de-scaling solutions, always wear appropriate personal protective clothing, protective gloves, and eye protection.

#### Step 2 - Dismantle the Droplet Separator

- Turn off and isolate electrical supplies to the unit.
- Remove all media cassettes.

#### Step 3 - Prepare the De-scaling Solution



CAUTION: Risk of emanation of gas irritants, ensure to perform these tasks in a well-ventilated area. It is recommended to perform the following steps outside.

- Mix the de-scaling solution according to the manufacturer's recommendations.
- Use a clean container of a suitable size to completely immerse each media cassette.
- Ensure that a second clean container of a suitable size is within reach and has been filled with clean, clear
  water to immerse each cassette after de-scaling.

#### Step 4 - Remove Scale from Individual Cassettes

- Using a soft brush, lightly brush any loose scale from the surface of the media.
- Lower the individual cassettes into the de-scaling solution.
- Keep each matrix cassette in the solution until the reaction between the calcium on the matrix and the descaling solution is complete.



Note: The effect of the de-scaling solution will vary depending on the condition of the media's material. For an improved effect, the above process may have to be repeated.

Clean and if necessary apply the de-scaling solution on all parts which are covered with scale.

#### Step 5 - Rinse

- Lift the individual cassettes out of the acid solution, while allowing any excess de-scaling solution to drip, and directly submerse them into the clean water container.
- If necessary, rinse a second time while profusely wetting the media.

#### Step 6 - Re-assemble and Restart

- Replace the media cassettes and media frames on the droplet separator.
- Reconnect the power supply.



### **Replacement Part Numbers**

| Component                 | Model                                | Part Number |
|---------------------------|--------------------------------------|-------------|
|                           | SKH100                               | SPH2011     |
|                           | SKH200                               | SPH2012     |
| D                         | SKH300                               | SPH2013     |
| Pump                      | SKH600                               | SPH2014     |
|                           | SKH900                               | SPH2015     |
|                           | SKH1200                              | SPH2016     |
| 5 microns PP pre-filter   | All models                           | VP PF05-10  |
| Silver ion cartridge      | All models                           | VP NS-10    |
| Pressure relief valve     | All models                           | SPH2021     |
| Low pressure manometer    | All models                           | SPH2100     |
| High pressure manometer   | All models                           | SPH2101     |
| I                         | SKH100 to SKH600                     | SPH2102     |
| Low pressure check valve  | SKH900 & SKH1200                     | SPH2130     |
|                           | SKH100 to SKH600                     | SPH2104     |
| Low pressure regulator    | SKH900 & SKH1200                     | SPH2105     |
| High pressure check valve | All models                           | SPH2023     |
| Solenoid valve            | All models                           | SPH2024     |
| 0.1 .1 .1                 | 60Hz models                          | SPH6031     |
| Solenoid coil             | 50Hz models                          | SPH6032     |
|                           | Nozzle cap                           | SPH2050-1   |
| ., ,                      | 6 lb/h (2.7 kg/h) nozzle             | SPH2050-3   |
| Nozzle                    | 8.8 lb/h (4 kg/h) nozzle             | SPH2050-4   |
|                           | 10.8 lb/h (4.9 kg/h) nozzle          | SPH2050-5   |
|                           | SKH100 (208, 230, 240V - 1ph)        | SPH6212     |
|                           | SKH100 (208, 230, 240V - 3ph)        | SPH6213     |
|                           | SKH100 (400, 480V - 3ph)             | SPH6214     |
|                           | SKH100 (600V, 3ph)                   | SPH6215     |
|                           | SKH200 (208, 230, 240V - 1ph)        | SPH6216     |
|                           | SKH200 (208, 230, 240V - 3ph)        | SPH6217     |
|                           | SKH200 (400, 480V - 3ph)             | SPH6218     |
|                           | SKH200 (600V, 3ph)                   | SPH6219     |
| Variable frequency drive  | SKH300 (208, 230, 240V - 3ph)        | SPH6228     |
|                           | SKH300 (400, 480V - 3ph)             | SPH6229     |
|                           | SKH300 (600V, 3ph)                   | SPH6230     |
|                           | SKH600 (208, 230, 240V - 3ph)        | SPH6221     |
|                           | SKH600 (400, 480V - 3ph)             | SPH6222     |
|                           | SKH600 (600V, 3ph)                   | SPH6223     |
|                           | SKH900 & 1200 (208, 230, 240V - 3ph) | SPH6224     |
|                           | SKH900 & 1200 (400, 480V - 3ph)      | SPH6225     |
|                           | SKH900 & 1200 (600V, 3ph)            | SPH6226     |

Page | 53 www.neptronic.com



| Component                                     | Model  | Part Number      |
|---|--|------------------|
|   | SKH100 (208 to 240V, 380 to 480V)              | SPH6108          |
|   | SKH100 (585 to 600V)                           | SPH6109          |
|   | SKH200 (208 to 240V, 380 to 480V)              | SPH6104          |
|   | SKH200 (585 to 600V)                           | SPH6105          |
|   | SKH300 (208 to 240V, 380 to 480V)              | SPH6113          |
| Motor   | SKH300 (585 to 600V)                           | SPH6114          |
|   | SKH600 (208 to 240V, 380 to 480V)              | SPH6106          |
|   | SKH600 (585 to 600V)                           | SPH6112          |
|   | SKH900 & SKH1200<br>(208 to 240V, 380 to 480V) | SPH6107          |
|   | SKH900 & SKH1200 (585 to 600V)                 | SPH6110          |
|   | DFJ-6A   | SPH6001          |
|   | DFJ-10A  | SPH6003          |
|   | DFJ-15A  | SPH6004          |
|   | DFJ-20A  | SPH6005          |
| High speed fuse                               | DFJ-25A  | SPH6002          |
|   | DFJ-30A  | SPH6007          |
|   | DFJ-35A  | SPH6008          |
|   | DFJ-60A  | SPH6009          |
|   | DFJ-80A  | SPH6010          |
| Low voltage circuit fuse                      | All models                                     | SP5109           |
| Temperature sensor                            | All models                                     | SPH2601          |
| Pressure transmitter (0-87 psi [0-6 bar])     | All models                                     | SPH2602          |
| Pressure transmitter (0-2321 psi [0-160 bar]) | All models                                     | SPH2603          |
| Main PCB                                      | All models                                     | NW SKH-MASTERSS  |
| Pump unit PCB                                 | All models                                     | NW SKH-SLAVESS   |
| EZC PCB                                       | All models                                     | NW SKH-EZCSS     |
| Pump unit display board                       | All models                                     | NW SKV-DISPLAYSS |
| MDU motor fan                                 | MDU-120  | SPH4401          |
| NIDO MOLOI IAN                                | MDU-230  | SPH4402          |

Page | 54 www.neptronic.com



## neptronic

400 Lebeau blvd, Montreal, Qc, H4N 1R6, Canada www.neptronic.com

Toll-free in North America: 1-800-361-2308

Tel.: (514) 333-1433 Fax: (514) 333-3163

Customer service fax: (514) 333-1091

Monday to Friday: 8:00am to 5:00pm (Eastern Time)