



neptronic®

## EVCB44N Series

### BACnet Communication Module User Guide



EVCB44NIT0S (0 TRIACS / pressure independent)  
EVCB44NDT0S (0 TRIACS / pressure dependent)





## Contents

Introduction .....	1
Pre-requisites .....	1
Advantages of BACnet.....	1
BACnet Properties Configuration.....	2
Configuration Options .....	3
Quick Setup .....	3
Manual Setup .....	3
Mac Address and Max_Master .....	3
Copy Config.....	4
Network Reset.....	4
Device Object Properties .....	5
Object Types Supported .....	6
Out of Service Property.....	7
Object Table Information .....	8
Analog Input (AI) .....	8
Analog Output (AO).....	9
Analog Value (AV).....	9
Binary Input (BI) .....	15
Binary Value (BV).....	15
Multi State Value (MSV).....	18
Other.....	23
Notes .....	24



# Introduction

---

The EVCB Controller BACnet® Communication Module User Guide provides information about using the EVCB controller with BACnet communications feature. The BACnet communication protocol for building automation and control networks enables communication between client devices within a network. The controller provides a BACnet network interface between BACnet client devices and Neptronic Controller series devices. It uses the BACnet Master Slave/Token Passing (MS/TP) protocol at the BACnet MAC layer.

## Pre-requisites

The BACnet communication user guide assumes that you are familiar with the concepts of BACnet and its terminology.

## Advantages of BACnet

BACnet enabled controllers have the following advantages:

- **Quick Message Transmission.** The controller uses a synchronous implementation for BACnet messages making it quick and efficient. Each BACnet confirmed service request is answered as quickly as possible without using the **Reply Postponed** frame.
- **MS/TP Support.** The controller supports a Full Master Node state machine for MS/TP. Max\_Master and the instances are configured to the device object through **BACnet WriteProperty** service. The MAC address is set via menu or proprietary device property. Programming mode determines the MS/TP baud rate setting of 9600, 19200, 38400, and 76800. In the configuration mode, the device is configured through the device's keypad. For more information about the WriteProperty, refer to [Table 3 - Object Types Supported](#).
- **BIBB Support.** The controller functions the same way as the B-ASC type profile server and supports the specific BIBB as per their relevant definitions.
  - DS-RP-B
  - DS-RPM-B
  - DS-WP-B
  - DS-WPM-B
  - DM-DCC-B
  - DM-DDB-B
  - DM-DOB-B
  - DM-RD-B
  - DM-TS-B
  - DM-UTC-B
  - DS-COV-B
  - DS-COVP-B
  - SCHED-WS-I-B
- **Object Support.** The controller supports a fixed list of BACnet visible values, which appear as Present\_Values of various BACnet standard object types in addition to a device object. For more information, refer to [Table 3 - Object Types Supported](#).
- **Alarms.** The controller supports indication of various alarm conditions through value changes in properties of several objects. However, it does not generate BACnet event notifications.

## BACnet Properties Configuration

To establish communication on the network and guarantee a unique ID of devices in a BACnet system, the following properties may have to be configured.

**Table 1 - BACnet Properties Configuration**

Property	Default Value	Configuration
MAC Address	000	Set to a value between 000 and 254 via menu. The values from 128-254 represent MS/TP non-token passing slave devices.
Device Instance	Auto	<ul style="list-style-type: none"> <li>The controller automatically configures its device instance to 153,000 + MAC address.</li> <li>The value can be set manually via the menu.</li> <li>The value can be set manually through the <b>WriteProperty</b> service to <b>Device Object.Object_Identifier</b>.</li> <li>The device's <b>Object_Identifier</b> is a combination of the <b>Device Object_Type</b> (8) and the <b>Device_Instance</b> (0-4194302); therefore, its decimal or hexadecimal representation tends to be incomprehensible.</li> <li>For example, the <b>Device_Instance</b>=1000 has an equivalent <b>Object_Identifier</b> of 0x020003E8 hexadecimal or 33555432 decimal.</li> </ul>
Baud Rate	0 = Auto	<ul style="list-style-type: none"> <li>The controller configures its baud rate automatically by detecting the network upon connection.</li> <li>The value can be set manually from the available values of Auto, 9600, 19200, 38400, 76800.</li> </ul>
Max_Master	127	<ul style="list-style-type: none"> <li>Configure <b>Max_Master</b> value to increase network efficiency when there are less than 127 devices on the network.</li> <li>The <b>Max_Master</b> value can be changed via the menu or through the <b>WriteProperty</b> service to the <b>Device Object.Max_Master</b>.</li> </ul> <p>For more information, refer to the Mac Address and Max_Master section.</p>
Device Object.Object_Name	Name of the device	<ul style="list-style-type: none"> <li>Configure the name of the device through <b>WriteProperty</b> service to the <b>Device Object.Object_Name</b>. For example, EVCB44N.</li> </ul>

# Configuration Options

The following options enable you to configure and run the BACnet features of the controllers quickly.

## Quick Setup

Configure the controller's baud rate and device instance without programming.

1. Default device MAC address is 0 and default Device Instance is 153000.
2. Connect the controller to the network or separately and power it up.
3. The controller automatically configures the baud rate and device instance.
4. Change MAC address using device proprietary property #1000. Device instance will adjust automatically if it was never modified directly.
5. Repeat the steps for each controller.

## Manual Setup

To use a **Device\_Instance** other than 153,000, and /or if your site has more than one controller network, go to the digital room sensor menu.

1. Ensure the digital room sensor jumper is in the RUN position.
2. Press the **[\*]** and **[–]** buttons simultaneously for 5 seconds. The “Enter Password” screen appears.
3. Enter the 637 password within 1 minute by using the arrow keys to increase or decrease the value and the **[\*]** and **[–]** buttons to toggle between the digits.
4. Follow the menus to configure the MAC address, Max Master, Device Instance, and Baud Rate manually.
5. Disconnect the power to the controller, connect the controller to the network, and connect the power again.

Configure the **Max\_Master** value through **WriteProperty** service to the **Device Object.Max\_Master** to increase network efficiency or if there are less than 127 devices on the network.

## Mac Address and Max\_Master

The MAC address must be unique on the entire MS/TP network. However, having a unique MAC address and a high baud rate does not guarantee efficient operation of the controller and other MS/TP units on the MS/TP network. Some MAC address and Max\_Master combinations are more efficient than others. BACnet requires token-passing units to occasionally “poll” for other masters based on the MAC address and Max\_Master.

A poor combination of MAC addresses and Max\_Master can lead to a slower network due to lost time polling for masters that are not present. Unless there are 126 other units on the MS/TP network, the default Max\_Master value of 127 is not the most efficient choice for the controller. The Max\_Master default value of 127 was selected to ensure that any master, specifically a BACnet client can be found when the controller is initially started.

### Examples of Mac Address and Max\_Master Configurations

The following are some of the examples to indicate the optimum combination of Mac address and Max\_Master configurations to ensure a quick and efficient output.

#### Example 1

- MAC=0. Max\_Master=127
- MAC=1, Max\_Master=127

This configuration is slow and inefficient because every time either unit is required to find another master unit, it has to poll 126 units until it finds the right one to pass the token.

#### Example 2

- MAC=0. Max\_Master=5
- MAC=1 to MAC=4 is not used
- MAC=5, Max\_Master=5

This configuration is better than Example 1 but it is still slower. The Max\_Master is set to the most efficient value but the gap between the two MAC addresses is high. Therefore, each unit must poll four units until it finds the right one to pass the token.

#### Example 3

- MAC=0, Max\_Master=1
- MAC=2, Max\_Master=2

This is an incorrect configuration. The MAC=0 will never find MAC=2 because it will never poll for the master MAC address=2.

#### Example 4

- MAC=0, Max\_Master=3
- MAC=1, Max\_Master=3
- MAC=2, Max\_Master=3
- MAC=3, Max\_Master=3

This is an efficient configuration as the units are numbered consecutively and the MAX\_Master is set to the most efficient value. As a general guideline, the most efficient setup for an MS/TP network is one in which the units are consecutively numbered starting at MAC address 0 and having Max\_Master=the maximum MAC address in the system. If consecutive numbering is not possible, then the next most efficient setup is one in which all units have Max\_Master=the maximum MAC address in the system.

## Copy Config

Copy and broadcast the entire configuration of a controller to controllers of same type using the Copy Config feature.

1. Access Operation Mode (jumper set to RUN position).
2. Press and hold both function buttons for 5 seconds to access the Quick Access menu.
3. Enter the password, **637**.
4. Scroll to **Copy Config** programming menu and select **Yes**. Follow the rest of the onscreen instructions.



*Note: A Copy Config can also be executed via BACnet. See AV.165, AV.166, AV.167, and BV.90 in Table 6 - Object Table Information: Analog Value (AV) and Table 8 - Object Table Information: Binary Value (BV) for details.*

*However, the BACnet Schedule is not copied during a Copy Config operation.*

## Network Reset

Reset the controller via BACnet using the **Reinitialize Device** service. The Reinitialize Device service can be accessed using the following password: **nep**.

The Reinitialize Device service has two types of reset:

- *Warm Reset*. The Warm Reset restarts the controller with actual configuration.
- *Cold Reset*. The Cold Reset restarts the controller with **Factory configuration**.



**Warning:** *The Cold Reset erases the actual configuration when setting the MSTP address. Therefore, exercise caution while performing a Cold Reset.*

# Device Object Properties

The following table lists all the BACnet properties supported for the device object. The W indicates that the property is writable using the BACnet **WriteProperty** service.

**Table 2 - Device Object Properties**

Property	Value	Writable
Object_Identifier	<ul style="list-style-type: none"> <li>Programmable where the instance part of the Object_Identifier is in the range of 0-4194302</li> <li>The device instance must be unique system-wide</li> <li>The default value for the device instance=153000 (Vendor_Identifier*1000)</li> </ul>	W
Object_Name	EVCB44_, programmable up to 32 bytes	W
Description	Programmable up to 32 characters (default: BACnet VAV controller)	W
Object_Type	Device	
System_Status	Operational	
Vendor_Identifier	Always 153	
Vendor_Name	Always Neptronic	
Model_Name	Example, EVCB44N	Read Only
Firmware_Revision	Currently, 5.10	Read Only
Application_Software_Version	Currently, 2.03	Read Only
Protocol_Version	Always 1	Read Only
Protocol_Revision	Always 14	Read Only
DataBase_Revision	Default 0; incremented if Object Name and/or device ID change	Read Only
Max_APDU_Length_Accepted	Always 480	Read Only
Segmentation_Supported	(3) = No Segmentation	Read Only
APDU_Timeout	6000	W
Number_of_APDU_Retries	Always 3	Read Only
Local_Time	00:00:00	W
Local_Date	01-Jan-2015 (Thu)	W
Uts_Offset	-300 minutes	W
Daylight_Savings_Status	False	W
Backup_Failure_Timeout	300	W
Configuration_Files	File-1	
Last_Restore_Time	2015-01-01 (Thu), 00:00:00:00	
Backup_And_Restore_State	IDLE	
Backup_Preparation_Time	0	
Restore_Completion_Time	0	
Restore_Preparation_Time	0	
Protocol_Services_Supported	<ul style="list-style-type: none"> <li>subscribeCOV</li> <li>atomicReadFile</li> <li>atomicWriteFile</li> <li>readProperty</li> <li>readPropertyMultiple</li> <li>WriteProperty</li> <li>writePropertyMultiple</li> <li>deviceCommunicationControl</li> </ul>	<ul style="list-style-type: none"> <li>reinitializeDevice</li> <li>unconfirmedPrivateTransfer</li> <li>timeSynchronization</li> <li>who-Has</li> <li>who-Is</li> <li>utcTimeSynchronization</li> <li>subscribeCOVProperty</li> </ul>
Protocol_Object_Types_Supported	<ul style="list-style-type: none"> <li>analog-input</li> <li>analog-output</li> <li>analog-value</li> <li>binary-input</li> <li>binary-output</li> <li>binary-value</li> </ul>	<ul style="list-style-type: none"> <li>device</li> <li>file</li> <li>program</li> <li>schedule</li> <li>multi-state-value</li> </ul>
Object_List	166	Read Only
Device_Address_Binding	Always empty	
Max_Master	Programmable in the range of 0-127 (default: 127)	W
Max_Info_Frames	Always 1	
Proprietary property #1000	<ul style="list-style-type: none"> <li>Represents the MS/TP MAC address in the range of 0 to 254 (default: 0)</li> <li>Values 128 to 254 represent MS/TP non-token passing slave devices</li> </ul>	W



Property	Value	Writable
Proprietary property #1001	<ul style="list-style-type: none"> <li>Programmable (default: Auto)</li> <li>Represents the MS/TP Baud rate (unsigned type)</li> <li>Values are 0 (auto), 9600, 19200, 38400, 76800</li> <li>Reading this property always returns the actual Baud rate</li> </ul>	W
Proprietary property #1002	<ul style="list-style-type: none"> <li>Programmable (default: 15 minutes)</li> <li>Represents the period of time that an object in/out of service will automatically return to normal. Range = 0-120 minutes (unsigned type)</li> <li>Writing 0 means no automatic return to normal</li> </ul>	W

## Object Types Supported

The following table lists all the BACnet properties supported for each object type. Most of the properties are locked. The exception is **Present\_Value**, which represents the dynamic operating values of the device, and the **Status\_Flag**, **Event\_State**, and **Reliability** properties, which reflect the availability of the **Present\_Value**. Unless otherwise specified, properties are not changeable.

Table 3 - Object Types Supported

Object Type	Enabled	Optional Properties Supported	Writable Properties	Notes
<i>Note: Writable properties are different for some objects. Refer to the respective Object Table information to know the writable property for objects.</i>				
Analog Input	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>Reliability</li> <li>Description</li> <li>Min_Present_Value</li> <li>Max_Present_Value</li> <li>Resolution</li> <li>COV-Increment</li> </ul>	<ul style="list-style-type: none"> <li>Out_of_Service</li> <li>COV-Increment</li> </ul>	<ul style="list-style-type: none"> <li>If "Out of Service" is true, Present_Value and Status_Flag become writable properties.</li> <li>Out_of_Service property is writable for objects to which Present_Value is not writable. Refer to Out of Service Property section on page 7 for more information.</li> <li>Object will automatically return to Normal after a programmable period of time. Refer to Proprietary property #1002 of Device Object in Table 2 - Device Object Properties.</li> </ul>
Analog Value	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>Reliability</li> <li>Description</li> <li>COV-Increment</li> <li>Priority_Array</li> <li>Relinquish_Default</li> </ul>	<ul style="list-style-type: none"> <li>Present_Value</li> <li>Out_of_Service</li> <li>COV-Increment</li> </ul>	<ul style="list-style-type: none"> <li>Present_Value property is writable for every AV object except AV.20, AV.23, AV.40, AV.45, AV.55.</li> <li>Out_of_Service property is writable for objects indicated in Table 6 - Object Table Information: Analog Value (AV) on page 9.</li> <li>Refer to Out of Service Property section on page 7 for more information.</li> <li>Object will automatically return to Normal after a programmable period of time. Refer to Proprietary property #1002 of Device Object in Table 2 - Device Object Properties. Some objects are commandable. In such cases, the priority-array and relinquish-default properties are available.</li> </ul>
Analog Output	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>Description</li> <li>Reliability</li> <li>Min-Pres-Value</li> <li>Max-Pres-Value</li> <li>Resolution</li> <li>COV-Increment</li> </ul>	<ul style="list-style-type: none"> <li>Present_Value</li> <li>COV-Increment</li> </ul>	
Binary Input	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>Reliability</li> <li>Active_Text</li> <li>Inactive_Text</li> <li>Description</li> </ul>	Out_of_Service	<ul style="list-style-type: none"> <li>If "Out of Service" is true, Present_Value and Status_Flag become writable properties.</li> <li>Out_of_Service property is writable for objects to which Present_Value is not writable. Refer to Out of Service Property section on page 7 for more information.</li> <li>Object will automatically return to Normal after a programmable period of time. Refer to Proprietary property #1002 of Device Object in Table 2 - Device Object Properties.</li> </ul>
Binary Value	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>Reliability</li> <li>Active_Text</li> <li>Inactive_Text</li> <li>Description</li> <li>Priority_Array</li> <li>Relinquish_Default</li> </ul>	Present_Value	<ul style="list-style-type: none"> <li>Present_Value property is writable for every Binary Value object.</li> <li>Out_of_Service property is writable for every Binary Value object.</li> <li>Some objects are commandable. In such case, the priority-array and relinquish-default properties are available.</li> <li>Object automatically returns to Normal after a programmable time. Refer to Proprietary property #1002 of Device Object in Table 2 - Device Object</li> </ul>

Object Type	Enabled	Optional Properties Supported	Writable Properties	Notes
				Properties.
Device	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>• Max_Master</li> <li>• Max_Info_Frame</li> <li>• Description</li> <li>• Active-COV-Subscriptions</li> <li>• #1000 (MSTP addr)</li> <li>• #1001 (Baud rate)</li> <li>• #1002 (Time out)</li> <li>• Local_Time</li> <li>• Local_Date</li> <li>• Uts_Offset</li> <li>• Daylight_Savings_Status</li> <li>• Apdu_Timeout</li> <li>• Backup_Failure_Timeout</li> </ul>	<ul style="list-style-type: none"> <li>• Object_Identifier</li> <li>• Object_Name</li> <li>• Max_Master</li> <li>• Description</li> <li>• Local_Time</li> <li>• Local_Date</li> <li>• Uts_Offset</li> <li>• Daylight_Savings_Status</li> <li>• Apdu_Timeout</li> <li>• Backup_Failure_Timeout</li> <li>• #1000</li> <li>• #1001</li> <li>• #1002</li> <li>• Configuration_Files</li> <li>• Last_Restore_Time</li> <li>• Backup_And_Restore_State</li> <li>• Backup_Preparation_Time</li> <li>• Restore_Completion_Time</li> <li>• Restore_Preparation_Time</li> </ul>	Refer to Table 2 - Device Object Properties on page 5.
Multi-State Value	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>• Description</li> <li>• Reliability</li> <li>• States_Text</li> </ul>	Present_Value	<ul style="list-style-type: none"> <li>• Present_Value property is writable for every Multi-State Value object except MSV.12 and MSV.13.</li> <li>• Out_of_Service property is not writable for MSV.</li> </ul>
Program	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>• Description</li> <li>• Reliability</li> </ul>	Program_Change	<ul style="list-style-type: none"> <li>• Only LOAD and RESTART are supported for Program Change.</li> <li>• Use LOAD to apply the new firmware.</li> </ul>
File	<input checked="" type="checkbox"/>	Description	<ul style="list-style-type: none"> <li>• Archive</li> <li>• File Size</li> </ul>	Only 0 is the accepted value to be written to file size.
Schedule	<input checked="" type="checkbox"/>	<ul style="list-style-type: none"> <li>• Description</li> <li>• Weekly Schedule</li> </ul>	<ul style="list-style-type: none"> <li>• Effective Period</li> <li>• Weekly Schedule</li> <li>• Schedule Default</li> <li>• Priority For Writing</li> <li>• Out_of_Service</li> </ul>	If "Out of Service" is true, Present_Value becomes writable property.

## Out\_of\_Service Property

Neptronic controllers offer the use of the Out of Service writable property. When the value of this property is set to True, it disconnects the object from physical input, enabling you to input other values. This is useful for special applications or while troubleshooting. For example, you can ignore the temperature read from a sensor and input the desired temperature value to perform specific tests.

For security reasons, a timeout will set the Out of Service property back to False after 15 minutes. This value can be modified to between 0 and 120 minutes (For more information, see proprietary property #1002 in [Table 2 - Device Object Properties](#)).



# Object Table Information

The EVCB44N Controller series uses the following BACnet object tables, categorized based on their ID. The type is the BACnet Object type, the instance is the BACnet Object. Together, the type and instance form the **BACnet Object Identifier** for an object according to the following C-language algorithm:

- object\_identifier=(unsigned long)((unsigned long)type<<22)+instance

## Analog Input (AI)

Table 4 - Object Table Information: Analog Input (AI)

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
AI.1	AnalogInput1	Status value in volts of Analog Input 1.	Out of service COV Increment (0.5)	x	x	0.00 to 10.00 Vdc, Resolution 0.01 V
AI.3	InternTemp	Status of the intern temperature sensor (ITS). This is the value read by the integrated temperature sensor of the TRL/TDU.	Out of service COV Increment (0.5)	x	x	32°F to 122°F or 0°C to 50°C Resolution 0.02°F/0.01°C
AI.5	InternHumidity	Humidity reading of on board humidity sensor of TRLH or TRLGH24/TDU (models with humidity sensor) unit.	Out of service COV Increment (0.5)	x	x	5% RH to 95% RH, Resolution 0.1% RH
AI.6	Intern_CO2	CO <sub>2</sub> reading of on-board sensor of TRLG24 or TRLGH24/TDU (models with CO <sub>2</sub> sensor) unit.	Out of service COV Increment (50)	x	x	0 to 2000 ppm, Resolution 1 ppm
AI.8	InternVOCSensor	Internal VOC sensor reading.	Out of service COV Increment (0.5)	x	x	0.00 to 10.00, Resolution 0.01

## Analog Output (AO)

**Table 5 - Object Table Information: Analog Output (AO)**

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
AO.1	AnalogOutput1	Status value that represents the modulation percentage of analog output 1 based on demand.	Present Value COV Increment (0.5)	x	x	0 to 100%, Resolution 0.1%

## Analog Value (AV)

**Table 6 - Object Table Information: Analog Value (AV)**

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
AV.1	ControlTemp	Status of the control temperature used to calculate demand. This value is configured with MSV.4 (Cfg_TempControlSource).	Out of service Writable if MSV.4 is set to "Network Sensor" COV Increment (0.5)	x	x	-40°F to 212°F or -40°C to 100°C Resolution 0.02°F/0.01°C
AV.2	ExternTemp	Status of the external temperature sensor. This is the value read by the external temperature sensor when MSV.1 (Cfg_UniversalInputAI1 Type) is set to Extern Sensor (EtS).	Out of service COV Increment (0.5)	x	x	-40°F to 212°F or -40°C to 100°C Resolution 0.02°F/0.01°C
AV.3	ChangeOverTemp	Status of the changeover temperature sensor. This is the value read by the changeover sensor when MSV.1 (Cfg_UniversalInputAI1 Type) is set to Changeover Sensor (SENS).	Out of service COV Increment (0.5)	x	x	-40°F to 212°F or -40°C to 100°C Resolution 0.02°F/0.01°C
AV.4	AirSupplyTemp	Status of the air supply temperature sensor. This is the value read by the discharge temperature sensor when MSV.1 (Cfg_UniversalInputAI1 Type) is set to Air Supply Temp (Ast). Note that this value is for reference only. No action is linked to this temperature.	Out of service COV Increment (0.5)	x	x	-40°F to 212°F or -40°C to 100°C Resolution 0.02°F/0.01°C
AV.5	CO2 SensorValue	Status of the carbon dioxide sensor (CO2). This is the value read CO2 sensor in parts per million (PPM) when MSV.1 (Cfg_UniversalInputAI1 Type) is set to CO2 sensor (CO2). AV.140 (Cfg_CO2 Range) and AV.141 (CO2 Setpoint) must be configured for proper reading.	Out of service COV Increment (50)	x	x	0 to AV.140 PPM, Resolution 1 PPM

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
AV.6	ControlSetPoint	Status of the actual temperature control setpoint value. In occupied/day mode, the setpoint is defined by AV.15 (TempSetPoint). In night setback or unoccupied mode, the setpoint is defined by AV.18 (SetPointCoolNoOccNSB) and/or AV.19 (SetPointHeatNoOccNSB).	Out of service COV Increment (0.5)	x	x	50°F to 104°F or 10°C to 40°C Resolution 1°F/0.5°C
AV.10	Cfg_InternalTempOffset	Configuration value used to calibrate the integrated temperature sensor of the TRL/TDU (ItS).	Present Value COV Increment (0.1)	x	x	±10°F or ±5°C, Resolution 0.2°F/0.1°C
AV.11	Cfg_ExternTempOffset	Configuration value used to calibrate the external temperature sensor (EtS).	Present Value COV Increment (0.1)	x	x	±10°F or ±5°C, Resolution 0.2°F/0.1°C
AV.15	TempSetPoint	Configuration value used to set the actual user setpoint of the zone in occupied/day mode. This value may be locked to prevent the user from changing the setpoint (BV.2).	Present Value COV Increment (0.5)	x	x	AV.16 to AV.17, Resolution 1°F/0.5°C
AV.16	Cfg_MinSetPoint	Configuration value used to set the user minimum permitted setpoint of the zone in occupied/day mode.	Present Value COV Increment (0.5)	x	x	50°F to AV.17 or 10°C to AV.17 Resolution 1°F/0.5°C
AV.17	Cfg_MaxSetPoint	Configuration value used to set the user maximum permitted setpoint of the zone in occupied/day mode.	Present Value COV Increment (0.5)	x	x	AV.16 to 104°F or AV.16 to 40°C Resolution 1°F/0.5°C
AV.18	SetPointCoolNoOccNSB	Configuration value of the cooling setpoint when in night setback or unoccupied. BV.20 (Cfg_NightSetBackMode) must be set to Setpoint for the value to be active.	Present Value COV Increment (0.5)	x	x	AV.19 to 104°F or AV.19 to 40°C Resolution 1°F/0.5°C
AV.19	SetPointHeatNoOccNSB	Configuration value of the heating setpoint when in night setback or unoccupied. BV.20 (Cfg_NightSetBackMode must be set to Setpoint for the value to be active.	Present Value COV Increment (0.5)	x	x	50°F to AV.18 or 10°C to AV.18 Resolution 1°F/0.5°C
AV.20	HeatingDemand1	Status value that represents the heating demand in percentage for Heating Ramp 1. This value is based on zone temperature, zone setpoint and values set for the actual ramp (AV.21 and AV.22).	Read only COV Increment (5)	x	x	0 to 100%, Resolution 0.5%
AV.21	Cfg_HeatingPropBand1	Configuration value that represents the range through which the controller will modulate the heating output from 0-100%.	Present Value COV Increment (0.5)	x	x	1°F to 10°F or 0.5°C to 5°C, Resolution 1°F/0.5°C
AV.22	Cfg_HeatingDeadBand1	Configuration value that represents the range where the controller will not take action when below the zone setpoint.	Present Value COV Increment (0.1)	x	x	0°F to 10°F or 0°C to 5°C, Resolution 0.2°F/0.1°C
AV.23	HeatingDemand2	Status value that represents the heating demand in percentage for the Heating Ramp 2. This value is based on zone temperature, zone setpoint and values set for the actual ramp (AV.24 and AV.25).	Read only COV Increment (5)	x	x	0-100%, Resolution 0.5%
AV.24	Cfg_HeatingPropBand2	Configuration value that represents the range through which the controller will modulate the heating output from 0-100%.	Present Value COV Increment (5)	x	x	1°F to 10°F or 0.5°C to 5°C, Resolution 1°F/0.5°C
AV.25	Cfg_HeatingDeadBand2	Configuration value that represents the range where the controller will not take action when below the zone setpoint.	Present Value COV Increment (0.1)	x	x	0°F to 10°F or 0°C to 5°C, Resolution 0.2°F/0.1°C
AV.30	Cfg_IntegralTimeHeating	Configuration value that represents the reciprocal of the integral time in seconds (1/l or repeats per second). To obtain a slower reaction time, the value of the integral must be small. To obtain a quicker reaction, the integral must be bigger.	Present Value COV Increment (5)	x	x	0-250 seconds, Resolution 5 seconds

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
AV.40	CoolingDemand1	Status value that represents the cooling demand for Cooling Ramp 1. This value is based on zone temperature, zone setpoint and values set for the actual ramp (AV.41 and AV.42).	Read only COV Increment (5)	x	x	0-100%, Resolution 0.5%
AV.41	Cfg_CoolingPropBand1	Configuration value that represents the range through which the controller will modulate the cooling output from 0-100%.	Present Value COV Increment (0.5)	x	x	1°F to 10°F or 0.5°C to 5°C Resolution 1°F/0.5°C
AV.42	Cfg_CoolingDeadBand1	Configuration value that represents the range at which the controller will not take action when above the zone setpoint.	Present Value COV Increment (0.1)	x	x	0°F to 10°F or 0°C to 5° Resolution 0.2°F/0.1°C
AV.45	CoolingDemand2	Status value that represents the cooling demand for Cooling Ramp 2. This value is based on zone temperature, zone setpoint and values set for the actual ramp (AV.46 and AV.47).	Read only COV Increment (5)	x	x	0-100%, Resolution 0.5%
AV.46	Cfg_CoolingPropBand2	Configuration value that represents the range through which the controller will modulate the cooling output from 0-100%.	Present Value COV Increment (0.5)	x	x	1°F to 10°F or 0.5°C to 5°C Resolution 1°F/0.5°C
AV.47	Cfg_CoolingDeadBand2	Configuration value that represents the range at which the controller will not take action when above the zone setpoint.	Present Value COV Increment (0.1)	x	x	0°F to 10°F or 0°C to 5°C Resolution 0.2°F/0.1°C
AV.50	Cfg_IntegralTimeCooling	Configuration value that represents the reciprocal of the integral time in seconds (1/l or repeats per second). To obtain a slower reaction time, the value of the integral must be small. To obtain a quicker reaction, the integral must be bigger.	Present Value COV Increment (5)	x	x	0-250 seconds, Resolution 5 seconds
AV.55	ChangeOverDemand	Status value that represents the changeover demand for the VAV box. This value is based on zone temperature, zone setpoint and values set for the actual ramp (AV.56 and AV.57).	Read Only COV Increment (5)	x	x	0-100%, Resolution 0.5%
AV.56	Cfg_ChangeOverPropBand	Configuration value that represents the range through which the controller will modulate the changeover output from 0-100%.	Present Value COV Increment (0.5)	x	x	1°F to 10°F or 0.5°C to 5°C Resolution 1°F/0.5°C
AV.57	Cfg_ChangeOverDeadBand	Configuration value that represents the range at which the controller will not take action when above or below the zone setpoint.	Present Value COV Increment (0.1)	x	x	0°F to 10°F or 0°C to 5°C Resolution 0.2°F/0.1°C
AV.58	ChangeOverSetPoint	Configuration value of the temperature at which the primary air from the central system is considered to be in cooling or heating. Note that there is a 1.5°C (2.7°F) dead band on each side of the setpoint.	Present Value COV Increment (0.5)	x	x	50°F to 104°F or 10°C to 40°C Resolution 1°F/0.5°C
AV.60	Cfg_NSBSetsBackOverrideDelay	Configuration time in minutes when in night setback and an override has been activated on the TRL/TDU.	Present Value COV Increment (5)	x	x	0 to 180 minutes, Resolution 15 minutes
AV.61	Cfg_NoOccOverrideDelay	Configuration time in minutes when unoccupied and an override has been activated on the TRL/TDU.	Present Value COV Increment (1)	x	x	0 to 180 minutes, Resolution 15 minutes
AV.62	Cfg_OccupancyMinTime	Configuration time in minutes for minimum time to maintain occupancy mode on the on-board motion sensor, if available.	Present Value COV Increment (1)	x	x	0 to 240 minutes, Resolution 1 minutes
AV.70	Cfg_AnalogOutput1Min	This value represents the minimum control signal of the controlled element. If the signal is 0-10Vdc then the minimum value is 0 Volts and if the signal is 2-10 Vdc then minimum value is 2 Volts. This value is the 0 position at 0% demand. If set at 2 Volts, a 2 Volt is applied continuously even when there is no demand. It is not used to set the minimum starting activation position.	Present Value COV Increment (0.5)	x	x	0 Volt to AV.71, Resolution 0.1 Volt

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
AV.71	Cfg_AnalogOutput1Max	This value represents the maximum control signal of the controlled element. If the signal is 0-10Vdc or 2-10Vdc then the maximum value is 10 Volts. It can also be used to limit the maximum output of the EVC. If the control signal is 0-10Vdc and the maximum voltage value is set to 8 Volts, the controlled element will never go over 80% of its total capacity.	Present Value COV Increment (0.5)	x	x	AV.70 to 10.0 Volt, Resolution 0.1 Volt
AV.89	Cfg_MotorMinPositionCoolHeat	Configuration value of the minimum position in cooling/heating mode the VAV box is allowed. This value is available for pressure dependent boxes or if BV.52 Pressure Mode Change is activated.	Present Value COV Increment (0.1)	x	x	0 to 100%, Resolution 1%
AV.90	Cfg_MotorMinPositionCool	Configuration value of the minimum position in cooling mode the VAV box is allowed. This value is available for pressure dependent boxes or if BV.52 Pressure Mode Change is activated.	Present value COV Increment (1)	x	x	0 to 100%, Resolution 5%
AV.91	Cfg_MotorMinPositionHeat	Configuration value of the minimum position in heating mode the VAV box is allowed. This value is available for pressure dependent boxes or if BV.52 Pressure Mode Change is activated.	Present Value COV Increment (1)	x	x	0 to 100%, Resolution 5%
AV.93	MotorPosition	Status value that represents the damper actuator position.	Out of service COV Increment (1)	x	x	0 to 100%, Resolution 1%
AV.100	Cfg_PressureNumFilter	Configuration value used to stabilize the reading of the differential pressure transducer when balancing.	Present Value COV Increment (5)	x		0 to 10 seconds, Resolution 1 second
AV.101	Cfg_AirFlowVnomOrKFactor	Configuration value that represents the maximum airflow of the VAV box at 1" w.c.	Present Value COV Increment (5)	x		100 to 9995 No units, Resolution 5 No units
AV.102	Cfg_AirFlowCoolMin	Configuration value that represents the minimum cooling airflow when system is in cooling mode.	Present Value COV Increment (5)	x		0 to 9995 No units, Resolution 5 No units Restricted by AV.103 and Airflow sensor precision
AV.103	Cfg_AirFlowCoolMax	Configuration value that represents the maximum cooling airflow when system is in cooling mode.	Present Value COV Increment (5)	x		(12.7%) Kfac to 9,995, Resolution 5 No units Restricted by AV.102 and Airflow sensor precision
AV.104	Cfg_AirFlowHeatMin	Configuration value that represents the minimum heating airflow when system is in heating mode.	Present Value COV Increment (5)	x		0 to 9,995 No units, Resolution 5 No units Restricted by AV.105 and Airflow sensor precision
AV.105	Cfg_AirFlowHeatMax	Configuration value that represents the maximum heating airflow when system is in heating mode.	Present Value COV Increment (5)	x		(12.7%) Kfac to 9,995, Resolution 5 No units Restricted by AV.104 and Airflow sensor precision
AV.106	Cfg_AirFlowIntegralTime	Configuration value that represents the reciprocal of the integral time in seconds (1/l or repeats per second). To obtain a slower reaction time, the value of the integral must be small. To obtain a quicker reaction, the integral must be bigger.	Present Value COV Increment (1)	x		0 to 60 minutes, Resolution 1 minute
AV.110	ActualAirFlow	Status value that represents the actual converted airflow measured by the differential pressure transducer.	Out of Service COV Increment (1)	x		0 to 9995 No units, Resolution 1 No units Restricted by AV.102, AV.103, AV.104, AV.105

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
AV.111	AirFlowSetPoint	Status value that represents the airflow calculated by demand.	Out of Service COV Increment (1)	x		0 to 9995 No units, Resolution 1 No units Restricted by AV.102, AV.103, AV.104, AV.105
AV.112	Cfg_AdjustAirFlowMax	Configuration value used during airflow balancing sequence. Refer to <a href="#">EVCB-Airflow Balance</a> Instructions.	Present Value COV Increment (1)	x		0 to 9,995 No units, Resolution 1 No unit Writable only if system is in balancing mode
AV.113	Cfg_AdjustAirFlowMin	Configuration value used during airflow balancing sequence. Refer to <a href="#">EVCB-Airflow Balance</a> Instructions.	Present Value COV Increment (1)	x		0 to 9,995 No units, Resolution 1 No unit Writable only if system is in balancing mode
AV.114	Cfg_AirFlowOffset	Configuration value used to adjust the calibration of the differential pressure transducer. Refer to <a href="#">EVCB Airflow Balance</a> Instructions.	Present Value COV Increment (1)	x		-500 to 500 No units, Resolution 1 No unit
AV.116	Cfg_AirFlowHysteresisStop	Configuration value that represents the airflow setpoint percentage used to prevent damper actuator oscillations. The actuator stops moving when in range of the airflow setpoint percentage value. Consult Neptronic technical support before changing this value.	Present Value COV Increment (1)	x		1 to 100%, Resolution 1%
AV.117	Cfg_AirFlowHysteresisStart	Configuration value that represents the airflow setpoint percentage used to prevent actuator from oscillating. The damper actuator starts moving when the airflow setpoint percentage value is out of range. Consult Neptronic technical support before changing this value.	Present Value COV Increment (1)	x		1 to 100%, Resolution 1%, Restricted by AV.116
AV.133	Cfg_Pressure_Reading	Status value that represents the value of the pressure sensor.	Out of Service COV Increment (5)	x		0 to 250Pa, Resolution 1Pa
AV.135	AirFlowFaultDeadBand	Configuration value that represents the airflow dead band used when BV.52 is activated. For advanced users or special applications only. We recommend that you use the default setting of 8%.	Present Value COV Increment (1)	x		1 to 30%, Resolution 1%
AV.136	AirFlowFaultError	Configuration value that represents the airflow fault error used when BV.52 is activated. For advanced users or special applications only. We recommend that you use the default setting of 40%.	Present Value COV Increment (1)	x		1 to 100%, Resolution 1%
AV.137	AirFlowFaultHysteresis	Configuration value that represents the airflow fault hysteresis used when BV.52 is activated. For advanced users or special applications only. We recommend that you use the default setting of 4%.	Present Value COV Increment (1)	x		1 to 30%, Resolution 1%
AV.138	AirFlowFaultTime	Configuration value that represents the airflow fault time used when BV.52 is activated. For advanced users or special applications only. We recommend that you use the default setting of 3 minutes.	Present Value COV Increment (1)	x		2 to 59 minutes, Resolution 1 minute
AV.140	CO2Range	Configuration value that represents the maximum range of the CO2 sensor (PPM) or the external sensor if CO2 enabled on AI1.	Present Value COV Increment (1)	x	x	100 to 5000 PPM, Resolution 1 PPM
AV.141	CO2Setpoint	Configuration value that represents the maximum limit of CO2 concentration before the EVC sends an alarm. If the value exceeds the limit, the motor will open at 100%, unless MSV.35 is set to Analog.	Present Value COV Increment (1)	x	x	100 to the greater ppm value between 2000 and AV.140

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
AV.145	NetworkTimeOut	Configuration time value. If MSV.4 is set to "Remote" and no value has been sent via BMS for more than AV.145 time, then EVC goes to "OFF" mode. AV.1 will display 999°C and object in Fault. If time is set to "0" minutes, AV.1 is reset to AV.15 value.	Present Value COV Increment (1)	x	x	0 to 60 minutes, Resolution 1 minute
AV.165	CopyCfgStartAddress	When using copy config, this value represents the first address in the range of copied controllers.	Present Value	x	x	0 to 254, Resolution 1
AV.166	CopyCfgEndAddress	When using copy config, this value represents the last address in the range of copied controllers.	Present Value	x	x	0 to 254, Resolution 1
AV.167	CopyCfgResult	When using copy config, this value is used to verify that the copy to the controllers was successful or failed.	Present Value	x	x	Succeed, Progerr, Typeerr, Modlerr, Memerr, Slave, Commerr
AV.170	CL_HT_SwitchTimer	Configuration value of the time required before the changeover is permitted to take place (time in minutes).	Present Value COV Increment (1)	x	x	0 to 120 minutes, Resolution 1 minute
AV.171	CL_HT_SwitchTimerCount	Status value of the remaining time before the changeover is authorised. This value counts down from the time set in AV.170.	Read Only COV Increment (1)	x	x	0 to 7200 seconds, Resolution 1 second, Writable
AV.190	Cfg_CO2PropBand	Configuration value that represents the range through which the controller modulates the CO <sub>2</sub> control output from 0 to 100%, when BV.101 is set to (1) Control ramp loop.	Present Value COV Increment (5)	x	x	50-250 ppm, Resolution 1 ppm
AV.191	Cfg_CO2DeadBand	Configuration value that represents the range at which the controller will not take action when below or above the CO <sub>2</sub> setpoint, when BV.101 is set to (1) Control ramp loop.	Present Value COV Increment (1)	x	x	10-50 ppm, Resolution 1 ppm
AV.192	AverageTemp	Status value that represents the average temperature of the combination of sensors selected using MSV.45 (Cfg_TempSensorCombo).	Out of Service	x	x	40°F to 212°F or -40°C to 100°C, Resolution: 0.018°F or 0.01°C
AV.193	MaximumTemp	Status value that represents the maximum temperature of the combination of sensors selected using MSV.45 (Cfg_TempSensorCombo).	Out of Service	x	x	40°F to 212°F or -40°C to 100°C, Resolution: 0.018°F or 0.01°C

## Binary Input (BI)

**Table 7 - Object Table Information: Binary Input (BI)**

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
BI.3	InternPIR	Status of the internal PIR sensor value: (0) NoOccupancy, (1) Occupancy.	Out of service	x	x	0 = NoOccupancy 1 = Occupancy

## Binary Value (BV)

**Table 8 - Object Table Information: Binary Value (BV)**

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
BV.1	Cfg_TempUnitBACnet	Configuration of the temperature units used in BACnet. If set to (0), the temperature will be in Celsius, if set to (1), the temperature will be in Fahrenheit.	Present Value	x	x	0 = Celsius, 1 = Fahrenheit
BV.2	Cfg_TempSetPointLock	Configuration to lock the zone setpoint and prevent users changing the value. (0) disable setpoint lock, (1) enable setpoint lock.	Present Value	x	x	0 = Disable, 1 = Enable
BV.3	UserSysOffMode	Configuration to allow users to turn off the EVC. (0) Enable user to turn off the EVC, (1) Disable prevents the user from turning off the EVC.	Present Value	x	x	0 = Enable, 1 = Disable
BV.4	Cfg_TempUnitTstat	Configuration of the user temperature units used on TRL/TDU. If set to (0), the temperature will be in Celsius, if set to (1), the temperature will be in Fahrenheit.	Present Value	x	x	0 = Celsius, 1 = Fahrenheit
BV.5	ChangeOverMode	Status value of the actual mode (0) Cooling, (1) Heating.	Present Value	x	x	0 = Cooling, 1 = Heating
BV.6	Cfg_FreezeProtection	Configuration to prevent a zone from falling below 4°C (39.2°F). If set to (1) On, the EVC will prevent the zone from freezing by activating the heating outputs even if the EVC is Off. If set to (0) Off, no action will be taken.	Present Value	x	x	0 = Off, 1 = On
BV.7	Cfg_KeyPadUpperLeftLock	Configuration to lock the Cool/Heat button. (0) Off, (1) On	Present Value	x	x	0 = Off, 1 = On (If set to "On", functionality of these buttons will not be available.)
BV.8	Cfg_KeyPadBottomLeftLock	Configuration to lock the °C/°F button. (0) Off, (1) On	Present Value	x	x	0 = Off, 1 = On If set to "On", functionality of these buttons will not be available.
BV.9	Cfg_KeyPadArrowsLock	Configuration to lock the arrow buttons. (0) Off, (1) On	Present Value	x	x	0 = Off, 1 = On If set to "On", functionality of these buttons will not be available.

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
BV.10	Cfg_ProgramLock	Configuration to lock all TRL/TDU buttons. (0) Off, (1) On	Present Value	x	x	0 = Off, 1 = On If set to "On", functionality of these buttons will not be available.
BV.20	Cfg_NightSetBackMode	Configuration to determine the action of the EVC when in night setback. When set to (0) setpoint, the EVC will maintain the setpoint values of AV.18 and AV.19. If set at (1) OFF, the EVC will turn off and will not take into consideration the setpoint values for cooling and heating.	Present Value	x	x	0 = Setpoint, 1 = OFF
BV.23	Cfg_OccControlSource	Determines the source of occupancy control to be used by the EVC.	Present Value	x	x	0 = Reserved, 1 = Intern Sensor
BV.25	Cfg_AnalogOutput1Direction	Configuration of the analog output direction. When set to (0) Direct, the signal ramp is configured to be from 0-10Vdc. When set to (1) Reverse, the signal ramp is configured to be from 10-0Vdc.	Present Value	x	x	0 = Direct, 1 = Reverse
BV.40	Cfg_MotorDirection	Damper actuator rotation direction configuration. When set to (0) Direct, the damper actuator is configured to open from 0° to 90°. When set to (1) Reverse the damper actuator is configured to open from 90° to 0°. When this value is changed, the EVC will execute an auto-stroke to reset the actuator's position.	Present Value	x	x	0 = Direct, 1 = Reverse
BV.41	Cfg_MotorPosControlTempFault	Control mode configuration for motor position when there is a temperature fault. When set to (0) Open, the position will remain fully open. When set to (1) Close, the position will stay at the minimum values defined by AV.89, 90 or 91.	Present Value	x	x	0 = Close, 1 = Open
BV.45	AirFlowBalancing	Airflow balancing enables configuration.	Present Value	x		0= Disable, 1= Enable
BV.50	Cfg_PressureModeSelect	Configuration value to configure the VAV box as (0) pressure independent or (1) pressure dependent.	Present Value	x		0= Independent, 1= Dependent
BV.51	PressureModeStatus	Status value that represents the actual pressure mode.	Read only	x		0= Independent, 1= Dependent
BV.52	PressureModeAutoChange	Configuration value to enable the VAV box to pass from pressure independent to pressure dependent in case of an airflow measurement fail.	Present Value	x		0 = Off, 1 = On
BV.53	AL_AirFlowError	Airflow error status. If BV.52 is set to (1) On, the controller will pass from pressure independent to pressure dependent.	Read only	x		0= No, 1= Yes
BV.55	AL_HighCO2Level	CO2 concentration above setpoint status. (0) No, (1) Yes.	Read only	x	x	0= No, 1= Yes
BV.60	Cfg_DisplayRH	Determines if the digital room sensor displays the %RH value. The display will alternate between %RH for 2 seconds and temperature for 8 seconds.	Present Value	x	x	0= Off, 1= On
BV.65	Cfg_DisplayCO2	Determines if the digital room sensor displays the CO2 value. CO2 is displayed on the first line above the temperature, replacing the time display.	Present Value	x	x	0= Off, 1= On
BV.66	Cfg_CO2ControlSource	CO2 reading source for control. Analog Input = external sensor on AI. TRLG = Onboard sensor of TRLG or TRLGH/TDU unit.	Present Value	x	x	0= Analog Input, 1= TRLG
BV.70	Cfg_ActiveSchedule	Schedule activation configuration. The schedule is configurable via BACnet. If no schedule is configured, the mode will always be occupied. On the TRL/TDU, the time and day will be displayed.	Present Value	x	x	0= No, 1= Yes

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
BV.90	CopyCfgExecute	<p>When using copy config, this value is used to start the copy to other controllers.</p> <p>Note: The BACnet schedule is not copied during a Copy Config operation.</p>	Present Value	x	x	0= No, 1= Yes
BV.100	Cfg_Fan Always On Mode	<p>Fan operation configuration when an output is configured as "Fan On". When set to (0) On, the fan is continuously in operation even when EVC is off. When set to (1) Off, the fan turns off during the following conditions: MSV.17 User System Mode is set to OFF, when in night setback mode or scheduler forces the EVC OFF.</p>	Present Value	x	x	0 = On, 1 = Off
BV.101	Cfg_CO2ControlMode	<p>Control mode configuration for the CO<sub>2</sub> control output. When set to (0) Open, the CO<sub>2</sub> control output will remain fully open. When set to (1) Control ramp loop, the CO<sub>2</sub> control output will vary based on the values defined by AV.190 and AV.191.</p>	Present Value	x	x	0 = Open, 1 = Control ramp loop



## Multi State Value (MSV)

Table 9 - Object Table Information: Multi State Value (MSV)

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
MSV.1	Cfg_UniversalInputAI1 Type	<p>Configuration of the input.</p> <p><b>Off (OFF):</b> Input not used.</p> <p><b>Extern Sensor (EtS):</b> Input set to 10kΩ external temperature sensor .</p> <p><b>Changeover Sensor (SENS):</b> Input set to 10kΩ Changeover Sensor.</p> <p><b>Changeover Contact Normally Open Cool (NoCL):</b> Input set as a changeover contact. When contact is opened, the system is in cooling mode. When contact is closed, the system is in heating mode.</p> <p><b>Changeover Contact Normally Open Heat (NoHt):</b> Input set as a changeover contact. When contact is opened, the system is in heating mode. When contact is closed, the system is in cooling mode.</p> <p><b>Airflow Setpoint (StFL):</b> Input set to slave mode . See MSV.35 (Cfg_MotorRamp) in Airflow Setpoint mode.</p> <p><b>CO2 Sensor (CO2):</b> Input set to 0-10Vdc CO2 sensor. See <a href="#">AV.140 (CO2 Range)</a> to set ppm sensing range.</p> <p><b>Air Supply Temp (Ast):</b> Input set to a 10kΩ discharge temperature sensor. This value is for information only. No action is taken by the EVC.</p> <p><b>Motor Position (mor):</b> Input set to 0-10Vdc slave mode. The input acts directly on the damper actuator when MSV.35 (Cfg_MotorRamp) is set to Analog (0-10Vdc).</p> <p><b>Sensor External 50K (E50):</b> Input set to a 50kΩ external temperature sensor.</p> <p><b>TSTAT Temperature Sensor (tESE):</b> Input set to 0-10Vdc temperature sensor from thermostat. The scaled input is read as the temperature input on the control temperature source.</p> <p><b>TSTAT Setpoint (StP1):</b> Input set to 0-10VDC setpoint from thermostat. The scaled input is read as the proportional setpoint value in the range of 0-50°C (32-122°F), within the limits set by AV.16 (Cfg_MinSetPoint) and AV.17 (Cfg_MaxSetPoint).</p> <p><b>TSTAT Setpoint 2-10V (StP2):</b> Input set to 2-10VDC setpoint from thermostat. The scaled input is read as the proportional setpoint value in the range of 0-50°C (32-122°F), within the limits set by AV.16 (Cfg_MinSetPoint) and AV.17 (Cfg_MaxSetPoint).</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Off</li> <li>• ExternSensor</li> <li>• ChangeOverSensor</li> <li>• ChOvContactNormCool</li> <li>• ChOvContactNormHeat</li> <li>• AirFlowSetPoint*</li> <li>• CO2Sensor</li> <li>• AirSupplyTemp</li> <li>• MotorPosition (mor)</li> <li>• ExternSensor50K</li> <li>• TSTAT Temp Sensor</li> <li>• TSTAT Setpoint</li> <li>• TSTAT Setpoint 2-10V</li> </ul> <p>* not available with EVCB44NDT0S</p>
MSV.3	Cfg_ChangeOverControlMode	<p>Indicates where the changeover value is coming from.</p> <p><b>Locally:</b> Analog input is configured in the EVC and will execute the changeover with the set parameters.</p> <p><b>Cooling:</b> Changeover is sent and controlled by the BMS. No changeover will occur unless the BMS sends a signal to do so.</p> <p><b>Heating:</b> Changeover is sent and controlled by the BMS. No changeover will occur unless the BMS sends the signal to do so.</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Locally</li> <li>• Cooling</li> <li>• Heating</li> </ul>

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
MSV.4	Cfg_TempControlSource	<p>Configuration value to set the control temperature to be used by the EVC.</p> <p><b>Internal Temperature (ItS):</b> The control temperature will be set to internal temperature sensor.</p> <p><b>External Temperature (EtS):</b> The control temperature will be set to external temperature sensor.</p> <p><b>Network Sensor (Net):</b> The control temperature will be set to Network (temperature sent by the BMS). See <a href="#">AV.145 (Cfg_NetworkTimeOut)</a> for safety feature.</p> <p><b>Average Temperature (AVE):</b> The control temperature will be set to the average temperature of the combined sensors defined by MSV.45 (Cfg_TempSensorCombo).</p> <p><b>Maximum Temperature (mA):</b> The control temperature will be set to the maximum temperature of the combined sensors defined by MSV.45 (Cfg_TempSensorCombo).</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• InternSensor</li> <li>• ExternSensor</li> <li>• NetworkSensor</li> <li>• Average Temp</li> <li>• Maximum Temp</li> </ul>
MSV.11	NsbOccCommand	<p>Configuration to set the occupancy or night setback mode.</p> <p><b>Locally:</b> Occupancy or Night setback is activated via occupancy sensor or schedule.</p> <p><b>OFF:</b> Forces the EVC Off. Signal sent via BMS.</p> <p><b>Occupancy:</b> Forces the EVC to occupied or day mode. Signal sent via BMS.</p> <p><b>No Occupancy:</b> Forces the EVC to unoccupied or night setback mode. Signal sent via BMS.</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Off   Occupancy   NoOccupancy</li> <li>• Locally   Off   Occupancy   NoOccupancy</li> <li>• Locally   Off   Day   Night</li> </ul>
MSV.12	OccupancyStatus	<p>Status that indicates the actual operation mode when occupancy is used. <b>No Occupancy:</b> Zone is not occupied.</p> <p><b>Occupancy:</b> Zone is occupied.</p> <p><b>Override:</b> Zone is unoccupied but put back to occupied mode for a maximum pre-determined time set at AV.61(Cfg_NoOccOverrideDelay).</p>	Read only	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• NoOccupancy</li> <li>• Occupancy</li> <li>• Override</li> </ul>
MSV.13	NightSetBackStatus	<p>Status that indicates the actual operation mode when night setback is used.</p> <p><b>Day:</b> Zone is in day operation.</p> <p><b>Night:</b> Zone is in night setback.</p> <p><b>Override:</b> Zone is in night setback but put back to day operation for a maximum pre-determined time set at AV.60 (Cfg_NSBSSetBackOverrideDelay).</p>	Read only	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Day</li> <li>• Night</li> <li>• Override</li> </ul>
MSV.16	UserSystemMode	<p>Status of the zone mode the user has set on the TRL/TDU. Not to be confused with the changeover mode of the system. These values may be restricted by MSV.17 (UserSysModeSelect).</p> <p><b>Auto (AutO):</b> Automatic mode changes from heating to cooling based on the zone demand.</p> <p><b>Heating (HEAt):</b> Heating mode is forced by the user. The zone will only consider the heating demand.</p> <p><b>Cooling (COOL):</b> Cooling mode is forced by the user. The zone will only consider the cooling demand.</p> <p><b>Off (OFF):</b> The EVC is forced to Off by the user. The EVC is inactive. This option is only available if BV.3 (UserSysOffMode) is set to (0) Enable.</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• Heating</li> <li>• Cooling</li> <li>• Off</li> </ul>

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
MSV.17	UserSysModeSelect	<p>Configuration to set the permissions or restrictions to change the zone mode by the user. This configuration affects MSV.16 (UserSystemMode) directly.</p> <p><b>Auto (Auto):</b> User has permission to change the mode from Auto, Cooling, Heating, and Off (if permitted by BV.3 UserSysOffMode).</p> <p><b>Heating (HEAt):</b> restricted to Heating mode and Off (if permitted by BV.3 UserSysOffMode).</p> <p><b>Cooling (COOL):</b> restricted to Cooling mode and Off (if permitted by BV.3 UserSysOffMode).</p> <p><b>Heating Or Cooling (On):</b> User is restricted to Heating or Cooling mode and Off (if permitted by BV.3 UserSysOffMode).</p> <p><b>Auto Lock (CLht):</b> User is restricted to Auto and Off (if permitted by BV.3 UserSysOffMode).</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Auto</li> <li>• Heating</li> <li>• Cooling</li> <li>• HeatingOrCooling</li> <li>• AutoLock</li> </ul>
MSV.20	Cfg_AnalogOutput1 Ramp	<p>Configuration of the ramp used to modulate AO.1 based on demand.</p> <p><b>Off:</b> Output not used.</p> <p><b>Cooling Ramp 1 (Cr1):</b> This ramp is used for cooling. The ramp is configured with AV.41 (Cfg_CoolingPropBand1) and AV.42 (Cfg_CoolingDeadBand1).</p> <p><b>Cooling Ramp 2 (Cr2):</b> This ramp is used for cooling. The ramp is configured with AV.46 (Cfg_CoolingPropBand2) and AV.47 (Cfg_CoolingDeadBand2).</p> <p><b>Heating Ramp 1 (Hr1):</b> This ramp is used for heating. The ramp is configured with AV.21 (Cfg_HeatingPropBand1) and AV.22 (Cfg_HeatingDeadBand1).</p> <p><b>Heating Ramp 2 (Hr2):</b> This ramp is used for heating. The ramp is configured with AV.24 (Cfg_HeatingPropBand2) and AV.25 (Cfg_HeatingDeadBand2).</p> <p><b>AirFlow Reading (ArFL):</b> This ramp is used for the airflow reading mode.</p> <p><b>CO2 Alarm (CO2):</b> This ramp is used to activate or deactivate controlled elements based on CO2 levels. The ramp is configured with AV.140 (Cfg_CO2 Range) and AV.141 (CO2 Setpoint). When BV.55 (AL_HighCO2Level) CO2 Alarm is activated, AO.1 will activate as well. With this option, AO.1 becomes a binary output (0 or 10Vdc).</p> <p><b>Airflow Setpoint (StFL):</b> This ramp is used as a master/slave control. The master controller must be set to Pressure Independent (BV.50) and will transmit a 0-10Vdc signal to the slave controller based on minimum/maximum airflows in heating and/or cooling mode. AV.70 (Cfg_AnalogOutput1 Min) and AV.71 (Cfg_AnalogOutput1 Max) will also affect the signal. The master controller's 0-10Vdc output resets based on the mode of the central unit (cool or heat) which is given by the changeover signal to match signal to the airflow setpoints (see analog input settings for changeover). The slave controller must be set to pressure independent and will convert the 0-10Vdc from the master to match the airflow setpoint. If a changeover is required for the master, it will also be required for the slave controller. Maximum and minimum cooling/heating Airflow setpoints are also required to operate correctly.</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• Off</li> <li>• CoolingRamp1</li> <li>• CoolingRamp2</li> <li>• HeatingRamp1</li> <li>• HeatingRamp2</li> <li>• AirFlowRead</li> <li>• CO2Alarm</li> <li>• AirflowSetpoint*</li> </ul> <p>* not available with EVCB44NDT05</p>

		Configuration of the ramp used to modulate the damper actuator based on demand. <b>Cooling Ramp 1 (Cr1):</b> This ramp is used when central system does cooling only. The ramp is configured with AV.41 (Cfg_CoolingPropBand1) and AV.42 (Cfg_CoolingDeadBand1). When the zone is in cooling demand, the EVC will modulate the damper actuator between the minimum and maximum cooling airflow setpoints (AV.102 and AV.103). When the zone is heating demand, the EVC will maintain the minimum cooling airflow setpoint (AV.102). <b>Cooling Ramp 2 (Cr2):</b> This ramp is used when central system does cooling only. The ramp is configured with AV.46 (Cfg_CoolingPropBand2) and AV.47 (Cfg_CoolingDeadBand2). When the zone is in cooling demand, the EVC will modulate the damper actuator between the minimum and maximum cooling airflow setpoints (AV.102 and AV.103). When the zone is heating demand, the EVC will maintain the minimum cooling airflow setpoint (AV.102). <b>Heating Ramp 1 (Hr1):</b> This ramp is used when central system does heating only. The ramp is configured with AV.21 (Cfg_HeatingPropBand1) and AV.22 (Cfg_HeatingDeadBand1). When the zone is in heating demand, the EVC will modulate the damper actuator between the minimum and maximum heating airflow setpoints (AV.104 and AV.105). When the zone is cooling demand, the EVC will maintain the minimum heating airflow setpoint (AV.104). <b>Heating Ramp 2 (Hr2):</b> This ramp is used when central system does heating only. The ramp is configured with AV.24 (Cfg_HeatingPropBand2) and AV.25 (Cfg_HeatingDeadBand2). When the zone is in heating demand, the EVC will modulate the damper actuator between the minimum and maximum heating airflow setpoints (AV.104 and AV.105). When the zone is cooling demand, the EVC will maintain the minimum heating airflow setpoint (AV.104). <b>Airflow Setpoint (StFL):</b> This ramp is used as a master/slave control. The master controller must be set to Pressure Independent (BV.50) and will transmit a 0-10Vdc signal to the slave controller based on minimum/maximum airflows in heating and/or cooling mode. AV.70 and AV.91 (Cfg_MotorMinPositionHeat) will also affect the signal. The master controller's 0-10Vdc output resets based on the mode of the central unit (cool or heat) which is given by the changeover signal to match signal to the airflow setpoints (see analog input settings for changeover). The slave controller must be set to pressure independent and will convert the 0-10Vdc from the master to match the airflow setpoint. If a changeover is required for the master, it will also be required for the slave controller. Maximum and minimum cooling/heating Airflow setpoints are also required to operate correctly. <b>Changeover Ramp (Cor):</b> This ramp is used when the central system does both heating and cooling. It requires a changeover sensor to operate. The ramp is configured with AV.56 (Cfg_ChangeOverPropBand) and AV.57 (Cfg_ChangeOverDeadBand). When the zone is in cooling demand, the EVC will modulate the damper actuator between the minimum and maximum cooling airflow setpoints (AV.102 and AV.103). When the zone is heating demand, the EVC will modulate the damper actuator between the minimum and maximum heating airflow setpoints (AV.104 and AV.105). <b>Cooling Heating Ramp 1 (CH1):</b> This ramp is used when central system does cooling only and a reheat coil is present at the zone level. The ramp is configured with AV.21 (Cfg_HeatingPropBand1), AV.22 (Cfg_HeatingDeadBand1), AV.41 (Cfg_CoolingPropBand1) and AV.42 (Cfg_CoolingDeadBand1). When the zone is in cooling demand, the EVC will modulate the damper actuator between the minimum and maximum cooling airflow setpoints (AV.102 & AV.103). When the zone is heating demand and a heating output is active, the EVC will modulate the damper actuator between the minimum and maximum heating airflow setpoints (AV.104 & AV.105). <b>Analog (ANLG):</b> This ramp is used to set the VAV box as a slave controller. The damper actuator follows the 0-10Vdc signal received by analog input 1 when MSV.1(Cfg_UniversalInputAI1 Type) is set to motor position.				
MSV.35	Cfg_MotorRamp		Present Value	x	x*	The available options vary based on selection of other objects. <ul style="list-style-type: none"><li>• CoolingRamp1</li><li>• CoolingRamp2</li><li>• HeatingRamp1</li><li>• HeatingRamp2</li><li>• AirFlowSetPoint*</li><li>• ChangeOverRamp</li><li>• CoolingHeatingRamp1</li><li>• Analog</li></ul> <p>* Airflow setpoint not available with EVCB44NDT0S.</p>
MSV.36	Cfg_NSBMotorMode	Configuration to set the motor position while in night setback.	Present Value	x	x	The available options vary based on selection of other objects. <ul style="list-style-type: none"><li>• Auto</li></ul>

ID	Name	Description	W?	EVCB44NIT05	EVCB44NDT05	Notes
		<b>Auto (AutO):</b> the damper actuator will modulate to maintain cooling and heating setpoints (AV.18 and AV.19). <b>Open (OPEn):</b> the damper actuator will open the VAV box to a fully open position.				<ul style="list-style-type: none"> <li>Open</li> </ul>
MSV.37	MotorPositionOverride	Configuration value to override the motor position. <b>Auto (AutO):</b> Motor position in automatic mode (no override). <b>Open (OPEn):</b> Motor position overridden to fully opened. <b>Close (CLOS):</b> Motor position overridden to fully closed. <b>Airflow Min (FLOL):</b> Motor position overridden to the minimum airflow of the current mode. When in heating mode, the position is minimum heating airflow (AV.104). When in cooling mode, the position is minimum cooling airflow (AV.102). <b>Airflow Max (FLOH):</b> Motor position overridden to the maximum airflow of the current mode. When in heating mode, the position is maximum heating airflow (AV.105). When in cooling mode, the position is maximum cooling airflow (AV.103).	Present Value	x	x	The available options vary based on selection of other objects. <ul style="list-style-type: none"> <li>Auto</li> <li>Open</li> <li>Close</li> <li>AirFlowMin (heat/cool as per current mode)</li> <li>AirFlowMax (heat/cool as per current mode)</li> </ul>
MSV.41	Cfg_AirFlowScale	Configuration value of the airflow scale used to get a better resolution when small airflows are configured. <b>Scale 1:</b> No scale is used. <b>Scale 10:</b> Airflow is multiplied by 10. This scale is used for low airflows up to 999. <b>Scale 100:</b> Airflow is multiplied by 100. This scale is used for very low airflows up to 99.	Present Value	x		The available options vary based on selection of other objects. <ul style="list-style-type: none"> <li>Scale1</li> <li>Scale10</li> <li>Scale100</li> </ul>
MSV.42	AirFlowBal_Mode	Position the damper actuator to preset positions. This object is used when balancing mode (BV.45) is activated. <b>Closed (CLOS):</b> The damper actuator moves to a fully closed position. Position used to calibrate airflow offset (AV.114). <b>Min Flow (min):</b> The damper actuator moves to the minimum airflow position of the actual mode it is in (AV.104 in heat or AV.102 in cool). Position used to calibrate the minimum airflow (AV.113). <b>Max Flow (mA):</b> The damper actuator moves to the maximum airflow position of the actual mode it is in (AV.105 in heat or AV.103 in cool). Position used to calibrate the maximum airflow (AV.112). <b>Full Open (OPEn):</b> The damper actuator moves to a fully opened position. Position used to calibrate the maximum airflow (AV.112).	Present value if BV.45 is set to Enable	x		The available options vary based on selection of other objects. <ul style="list-style-type: none"> <li>Closed</li> <li>Min Flow</li> <li>Max Flow</li> <li>Full Open</li> </ul>
MSV.45	Cfg_TempSensorCombo	Combination of sensors for average (AV.192) and maximum (AV.193) temperature readings. <b>TSTAT+AI1 (tA1):</b> Use the temperature sensor from the thermostat with an external temperature sensor on AI.1. <b>TSTAT+AI2* (tA2):</b> Use the temperature sensor from the thermostat with an external temperature sensor on AI.2. <b>TSTAT+AI1+AI2* (tA-):</b> Use the temperature sensor from the thermostat with the external temperature sensors on AI.1 and AI.2. <b>AI1+AI2* (A-):</b> Use the external temperature sensors on AI.1 and AI.2. <i>*AI2 is not available on EVCB44N series</i>	Present Value	x	x	The available options vary based on selection of other objects. <ul style="list-style-type: none"> <li>TSTAT+AI1</li> <li>TSTAT+AI2*</li> <li>TSTAT+AI1+AI2*</li> <li>AI1+AI2*</li> </ul> <p><i>*AI2 is not available on EVCB44N series</i></p>

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
MSV.95	Cfg_DisplayInfo	<p>Configuration value of the information displayed on the TRL/TDU.</p> <p><b>Display Temperature and Demand (t°C + Demand Icons):</b> The TRL/TDU will display the actual temperature and cooling/heating demand.</p> <p><b>Display Setpoint and Demand (StP + Demand Icons):</b> TRL/TDU will display the actual setpoint and cooling/heating demand.</p> <p><b>Display Temperature (t°C):</b> TRL/TDU will display the actual temperature but no demand.</p> <p><b>Display Setpoint (StP):</b> TRL/TDU will display the actual setpoint but no demand.</p> <p><b>Display Off (OFF):</b> TRL/TDU display will be off (no display).</p>	Present Value	x	x	<p>The available options vary based on selection of other objects.</p> <ul style="list-style-type: none"> <li>• TempAndDemand</li> <li>• SetpointAndDemand</li> <li>• TempOnly</li> <li>• SetpointOnly</li> <li>• Off</li> </ul>

## Other

**Table 10 - Object Table Information: Other**

ID	Name	Description	W?	EVCB44NIT0S	EVCB44NDT0S	Notes
PGM.1	ProgramFirmware	Program firmware. Set to LOAD to program the file in application memory. The controller will be reset and the firmware will be LOADED into memory. Use only the binary file provided by Neptronic.	Program Change	x	x	Program Change, only LOAD (1) and RESTART (4) are supported.
FIL.1	FirmwareBinaryFile	Firmware binary file. Set File Size to 0 to erase the previous binary file before uploading a new one. Use only the binary file provided by Neptronic.	File Size Archive	x	x	File Size is accepted for 0 value only.
SCH.1	OccupancySchedule	Weekly occupancy schedule to specify which occupancy state is active during specific periods of day.	Weekly Schedule Schedule Default Priority for Writing Effective Period Out of Service	x	x	

## Notes





**neptronic®**

400 Lebeau blvd, Montreal, Qc, H4N 1R6, Canada

[www.neptronic.com](http://www.neptronic.com)

Toll free in North America: 1-800-361-2308

Tel.: (514) 333-1433

Fax: (514) 333-3163

Customer service fax: (514) 333-1091

Monday to Friday: 8:00am to 5:00pm (Eastern time)