



neptronic[®]
www.neptronic.com

- HVAC Controls
- Electric Actuators
- Actuated Valves
- Humidifiers
- Electric Heaters

Head Office
Neptronic[®]
400 Lebeau Blvd.
Montreal, Quebec, Canada H4N 1R6
Tel.: (514) 333-1433
Fax: (514) 333-3163
Toll Free: 1-800-361-2308


Don't Forget! Reset the "Operating Hours" Counter

Servicing is a crucial step to keep a humidifier running well for as long as possible. To ensure proper servicing, Neptronic humidifiers are equipped with an "operating hours" counter, which lets you know when to service them. However, if you don't reset this counter every time maintenance is effectuated, it will not be able to send a notification for the next required servicing and the humidifier's performance will decrease as time passes. It is therefore extremely important to reset the operating hours counter every time the humidifier is serviced.

Here is the 4-step procedure to perform a reset on a SKR Residential Steam Humidifier:

1. Press the "POWER" push button to turn OFF the humidifier
2. Press and hold the "POWER" and "DRAIN" push buttons for 20 seconds
3. The red check light will turn off
4. Perform required maintenance

That's it, your humidifier's servicing is now complete and you will be notified when it is time to do it again. Resetting procedures for other models are available [here](#).



See the video and many others on our Youtube channel



USA
NEP Inc.
P.O. Box 1151
Medford Oregon,
USA 97501
Tel.: (541) 531-5746

Middle East & Asia
NEP International FZE
P.O. Box 125687,
Dubai, UAE
Tel.: +97155 8825487
Fax: +9714 3426772

Singapore
Neptronic Pte Ltd
Office D6, #03-38,
Mountbatten Square
229, Mountbatten Road,
Singapore – 398 007
Mobile: +65 8118 4184
Tel: +65 6650 6212
Fax: +65 6491 6423