

Rain Hood for Actuator

Specification and Installation Instructions

Description

Rain Hood (RH) protects actuators installed on valves against rain in outdoor installations.



Technical Specifications

Description	RH8
Actuator Compatibility	All Neptronic D, B, and S series actuators installed on Griswold Controls Unimizer valves (1/2" to 3", 2-way & 3-way)
Material	304 stainless steel
Access	Removable top panel
Ingress Protection	IP 54 equivalent to NEMA Type 3
Dimensions A = 5.25" 134 mm B = 9.5" 242 mm C = 5.5" 132 mm D = 11.63" 295 mm E = 7.38" 187 mm	E O C C




CAUTION: Rain Hood does not protect the actuators in corrosive and saline environments.

Mounting Instructions

The RH8 can be mounted either vertically or horizontally.

1. Remove the casing cover and wire the actuator according to the local electrical code. Ensure that UL listed electrical fittings for NEMA type 3 conditions are used for the hole provided.



2. Reattach the cover and ensure that the opening of the ventilation cup is always facing the ground. If the position of the ventilation cup is changed, ensure to tighten it firmly.

RH8-Rain Hood-200228 Page | 1