

Static Pressure Controller

Specification and Installation Instructions

Model Series

SPC

Description

The Neptronic Static Pressure Controller is used to modulate a damper or variable frequency drive to maintain a constant static or differential pressure at a given setpoint.

Applications

- Control bypass damper actuators, a VFD, or Vortex for VAV systems
- Laboratory pressurization control
- Stairwell pressurization control
- Energy saving

Features

- LCD Display
- Simple installation and configuration
- Displays actual pressure reading
- Adjustable setpoint and dead band
- Adjustable response speed
- Selectable output signal
- Direct or reverse action outputs
- Fully calibrated
- Real-time pressure output for remote monitoring

Models

| Model # | Pressure Range | Setpoint Range | Deadband |
|---------|-----------------------------|--------------------------------|---------------------------|
| SPC 0.1 | 0 - 0.1 "wc (0 - 0.025 KPa) | 0 - 0.099 "wc (0 - 0.0247 KPa) | 0 - 0.0121"wc (0.003 KPa) |
| SPC 1.0 | 0 - 1.0 "wc (0 - 0.25 KPa) | 0 - 0.99 "wc (0 - 0.247 KPa) | 0 - 0.121 "wc (0.03 KPa) |
| SPC 2.0 | 0 - 2.0 "wc (0 - 0.50 KPa) | 0 - 1.99 "wc (0 - 0.495 KPa) | 0 - 0.243 "wc (0.06 KPa) |
| SPC 5.0 | 0 - 5.0 "wc (0 - 1.25 KPa) | 0 - 4.99 "wc (0 - 1.242 KPa) | 0 - 0.613 "wc (0.153 KPa) |


Technical Specifications

| Specifications | SPC 0.1 SPC 1.0 SPC 2.0 SPC 5.0 | | |
|--|--|--|--|
| Power supply | 24 Vac ±10% | | |
| Power consumption | 3.6VA | | |
| Electrical connection | 18 AWG (8 mm ²) minimum on screw terminals | | |
| Input connection | 1/8" (3.175 mm) barbed fitting | | |
| | Actual pressure output: 0.25 to 4 Vdc | | |
| Output signals | Direct/Reverse acting output: 0 to 10 Vdc, 2 to 10 Vdc, 0 to 20 mA or 4 to 20 mA | | |
| Total error (not including long term stability) | Max. ±2.0% of full scale (from 10°C to 40°C [50°F to 104°F]) | | |
| Burst pressure | 1.5 PSI (10.3 KPa) either port | | |
| Response speed | Adjustable from 1 (100 mV/sec) to 25 (1.78 V/sec) (factory set: 2) | | |
| Contacts | Programmable ON & Off switching | | |
| Operating temperature | 0°C to 40°C [32°F to 104°F] Compensated: 5°C to 55°C [41°F to 131°F] | | |
| Storage temperature | -40°C to 80°C [-40°F to 176°F] | | |
| Dimensions A = 4.33" (110mm) B = 0.51" (13mm) C = 2.20" (56mm) D = 3.18" (81mm) E = 0.75" (19mm) F = 4.81" (122mm) | | | |



Typical Installation

In order to maintain a constant volume of air through the HVAC unit, a modulating bypass damper, VFD, or Vortex is used to control the air bypassed between the supply and return air ducts. The SPC is used to sense the supply air pressure and relieve excess air as the static pressure builds up.






Static Pressure Controller

Specification and Installation Instructions


Mechanical Installation

- 1. Affix the SPC on a DIN rail (by using the fittings and the screws provided) or directly on a wall or ventilation duct.
- 2. Insert the control pressure tube in the "HIGH" pressure port.
- 3. For differential pressure, insert the reference pressure tube in the "LOW" pressure port. Otherwise leave this entry with the free air.



Wiring

We strongly recommend that all Neptronic products be wired to a separate grounded transformer and that transformer shall service only Neptronic products. This precaution will prevent interference with, and/or possible damage to incompatible equipment.



Programming

Press the menu button ***** to enter programming mode. Once in programming mode, the menu button always goes to the next step. Use the arrow keys to change the value of the current menu item. Press and hold an arrow key to scroll rapidly scroll the values. Changes are automatically saved. The SPC automatically exits the menu after 20 seconds of inactivity.

| Step | Display | Description | Values |
|------|--|---|---|
| 1 | PR:X.XXX SP:X.XX | Operation Mode & Setpoint Adjustment When 24 Vac is supplied to the unit, the SPC displays the actual pressure (Pr) and the setpoint of the static pressure (Sp). Use the arrow keys to change the setpoint. | Increments of 0.01 Units in W.C. (inches of water column) Range 0.00 - 1.99 |
| 2 | DERDBRND (range 0.000-0.243) | Deadband Adjustment Prevents instability of the system caused by minor variations in static pressure. | Default: 0.050 (SPC 2.0) 0.050 (SPC 1.0) 0.012 (SPC 0.1) Increment: 0.010 (SPC 2.0) 0.010 (SPC 1.0) 0.001 (SPC 0.1) |
| 3 | RESPONSE SPEED (range 01-25) | Response Speed Adjustment Prevents unjustified changes due to a temporary surge of static pressure, which could affect the system. To increase system stability, we recommended setting the Response Speed to 1 (the lowest setting). | 1 to 25 (factory setting: #2) 1 lowest: (100 mV/sec, 100 seconds for a 0-10 Vdc output). 25 fastest: (1.78 V/sec, 5.6 seconds for 0-10 Vdc output). |
| 4 | CNTL OUT | Output Signal Adjustment The configuration of the output signal applies to both direct acting and reverse acting. | ▲ or ▼ = 0-10 Vdc / 2-10 Vdc |
| 5 | DIRECT RCT | Direct acting output configuration | • or $\mathbf{\nabla} = \text{Vdc or mA}$ |
| 6 | REVERSE RCT | Reverse acting output configuration | ▲ or ▼ = Vdc or mA |
| 7 | CONTRCT | Relay configuration | Direct or Reverse |
| 8 | CONTRET ON | Relay SETPOINT (Sp) to come ON | Contact Direct: 0.31-2.00 "wc Contact Reverse: 0.00-0.31 "wc |
| 9 | CONTRCT OFF | Relay SETPOINT (Sp) to turn OFF | Contact Direct: 0.00-0.31 "wc Contact Reverse: 0.31-2.00 "wc |

X

Recycling at end of life: please return this product to your Neptronic local distributor for recycling. If you need to find the nearest Neptronic authorized distributor, please consult **www.neptronic.com**.