






Feature:

| ire: | Old Number | |
|---|------------|----------|
| Retrofit assembly available for the | AQT1000A | AT000 |
| majority of the manufacturers of | AQT1005A | AT005 |
| valves (with option –XX-Y) | AQT1021A | AT020 |
| (see Retrofit option). | AQT1060A | AT060 |
| Variable running time. | AQT1065A | AT065 |
| Manuel override. | AQT1080A | AT080 |
| Maintenance free. | | AT000-30 |
| Fail safe by <i>Enerdrive System</i> ¹ | | AT005-30 |
| (on model 060, 065 & 080). | | AT020-30 |
| Auxiliary switches. | | AT060-30 |
| (on model 020 & 080). | | AT065-30 |
| | | AT080-30 |

| AT000 AQT 1000A | AT005 AQT 1005A | AT020 AQT 1021A | AT060 AQT 1060A | AT065 AQT 1065A | AT080 AQT 1080A | AT000 -30 | AT005 -30 | AT020 -30 | AT060 -30 | AT065 -30 | AT080 -30 |
|---|----------------------------------|---|--|--|---|---|--|--|---|--|---|
| No | No | Yes(2) | No | No | Yes(2) | No | No | Yes(2) | No | No | Yes(2) |
| No | Yes | No | No | Yes | No | No | Yes | No | No | Yes | No |
| | No Yes | | No | | | Yes | | | | | |
| | 6 VA 20VA Peak, 6VA | | 6 VA | | | 20VA Peak, 6VA | | | | | |
| | | | 2 wire / 2 position, g 4 wire / 3 point floating | | 3 wire / 2 position, 3 wire / 3 point floating | | | 2 wire / 2 position, 4 wire / 3 point floating | | | |
| 60 sec force dependant | | | | 3 | 30 sec force dependant | | | | | | |
| 100 lb. [450 N] at rated voltage | | | | | | | | | | | |
| 22 to 26 VAC or 28 to 32 VDC | | | | | | | | | | | |
| 18 AWG [0.8 mm ²] minimum | | | | | | | | | | | |
| 2 inlet bushing of 5/8 in [15.9 mm] & 7/8 in [22.2 mm] | | | | | | | | | | | |
| 1 in [25.4 mm] | | | | | | | | | | | |
| Reversible, normally open or normally close (factory set with normally close direction) | | | | | | | | | | | |
| 0°F to +122°F [-18°C to +50°C] | | | | | | | | | | | |
| -22°F to +122°F [-30°C to +50°C] | | | | | | | | | | | |
| 5 to 95 % non condensing. | | | | | | | | | | | |
| | 2 lbs. [0.9 kg] | | | | | | | | | | |
| | <u>1000A</u> No No 3 wi | 1000A 1005A No No No Yes No 6 VA 3 wire / 2 posi 3 point ft 6 6 | 1000A 1005A 1021A No No Yes(2) No Yes No No Yes No 6 VA 3 wire / 2 position, 3 wire / 3 point floating 60 sec force | 1000A 1005A 1021A 1060A No No Yes(2) No No Yes No No No Yes No No No Yes No No 6 VA 20% 3 wire / 2 position, 2 wire 3 wire / 3 point floating 4 wire 60 sec force dependa 2 2 2 inle 2 2 2 | 1000A 1005A 1021A 1060A 1065A No No Yes(2) No No No Yes No No Yes No Yes No No Yes No Yes No No Yes No Yes No Yes Yes 6 VA 20VA Peak, 6 3 wire / 2 position, 2 wire / 2 posi 4 wire / 3 point floating 3 wire / 3 point floating 4 wire / 3 point floating 100 l 60 sec force dependant 22 to 18 a 2 inlet bushing of 2 inlet bushing of 2 inlet bushing of | 1000A 1005A 1021A 1060A 1065A 1080A No No Yes(2) No No Yes(2) No Yes No No Yes No No Yes No No Yes No No Yes No No Yes No Some / 2 position, 3 wire / 3 point floating 2 wire / 2 position, 4 wire / 3 point floating 2 wire / 3 point floating 60 sec force dependant 100 lb. [450 N] 22 to 26 VAC of 18 AWG [0.8 m] 2 inlet bushing of 5/8 in [14] 2 inlet bushing of 5/8 in [14] 1 in [26] 1 in [26] 1 in [26] Reversible, normally open or normally close of to +122°F [-22°F to +122°F [-22°F to +122°F [| AQT 1000A AQT 1005A AQT 1021A AQT 1060A AQT 1065A AQT 1080A < | AQT 1000A AQT 1021A AQT 1021A AQT 1060A AQT 1065A AQT 1080A -30 -30 No No Yes(2) No No Yes(2) No No No Yes No No Yes No No Yes No Yes No No Yes No No Yes No Yes No Yes No No Yes No 6 VA 20VA Peak, 6VA 6 VA 6 VA 3 wire / 2 position, 3 wire / 3 point floating 3 | AQT 1000AAQT 1005AAQT 1021AAQT 1060AAQT 1065AAQT 1080A-30-30NoNoYes(2)NoNoYes(2)NoNoYes(2)NoYesNoNoYesNoNoYesNoNoYesNoYesNoYesNoYesNoNoYesNoYesNoYesNoYesNoSolutionYesYesNoYesNoYesNo6 VA20VA Peak, 6VA6 VA6 VA6 VA6 VA3 wire / 2 position, 3 wire / 3 point floating2 wire / 3 point floating3 wire / 3 point floating3 wire / 3 point floating60 sec force dependant100 lb. [450 N] at rated voltage30 sec force2 to 26 VAC or 28 to 32 VDC18 AWG [0.8 mm²] minimum2 inlet bushing of 5/8 in [15.9 mm] & 7/8 in [22.2 mm]1 in [25.4 mm]1 in [25.4 mm]1 in [25.4 mm]Core resible, normally open or normally close (factory set with normally close0°F to +122°F [-18°C to +50°C]-22°F to +122°F [-18°C to +50°C]-22°F to +122°F [-30°C to +50°C]-22°F to +122°F [-30°C to +50°C]-22°F to 95 % non condensing. | AQT 1000AAQT 1005AAQT 1021AAQT 1060AAQT 1065AAQT 1080ANoNoYesNoNoNoYesNoNoYesNoNoYesNoNoYesNoNoNoYesYesYesNoYesNoYesNoNoYesNoNoNoYesYesYesYesNoYesNoNoYesNoNoYes3 wire / 2 position, 3 wire / 3 point floating2 wire / 3 point floating3 wire / 3 point floating3 wire / 3 point floating4 wire60 sec force dependant100 lb. [450 N] at rated voltage30 sec force dependat30 sec force dependat2 inlet bushing of 5/8 in [15.9 mm] & 7/8 in [22.2 mm]1 in [25.4 mm]Reversible, normally open or normally close (factory set with normal | $\begin{tabular}{ c c c c c c } \hline A & a & a & a & a & a & a & a & a & a &$ |

Warning: Do not use automatic screw driver on manual override

Dimensions



Caution

We strongly recommend that all neptronic® products be wired to a separate transformer and that transformer shall service only neptronic® products. This precaution will prevent interference with, and/or possible damage to incompatible equipment. When multiple actuators are wired on a single transformer, polarity must be observed. Long wiring runs create voltage drop which may affect the actuator performance.


¹ Enerdrive Fail-Safe System: US Patent #5,278,454 | European Patent #0647366






Mechanical installation

| Mechanical installation | | | | | |
|-----------------------------|----------------------|---|--|--|--|
| Mounting of the actuator of | on valve | | | | |
| Correct mounting | Non Correct mounting | 1. Screw completely the valve shaft (C) unto the coupling of the actuator (A). | | | |
| | | Unscrew the coupling (A) for ½ of turn in order to leave a functional play. | | | |
| A GAP | | 3. Screw the counter nut (B). | | | |
| B [| | Warning: | | | |
| | | Do not over tight coupling of the actuator on the shaft of the valve. | | | |
| Mounting of the actuated | valve on system | | | | |
| Vertical mounting | Horizontal mounting | Pay attention to system particularity; be sure that the expansions, contractions of the system and its medium as well as operating pressures are within the tolerances. | | | |
| | | 2. When plumbing, the motorized valve should be situated in an easily accessible place and sufficient space should be allowed for the removal of the actuator. | | | |
| | | To prevent moisture from collecting in the motor casing, install the motorized valve such that the actuator is superior to the valve, at 20-30° / at vertical. Avoid mounting the valve so that the valve stem is below horizontal. | | | |
| Wiring Diagrams | | | | | |
| Models AT000, 005 & 02 | 20 | Models AT060, 065 & 080 | | | |
| AT000-30, 005-30 & 020 | -30 | AT060-30, 065-30 & 080-30 | | | |
| 3 wire / 2 position (ON-OI | | 2 wire / 2 position (ON-OFF) | | | |
| | 3 4 | | | | |
| COMMON (-) | SUPPLY (+) | | | | |
| | DRIVE UP (OPEN) | DRIVE UP (OPEN) | | | |
| 3 wire / 3 point floating | | 4 wire / 3 point floating | | | |
| 123 | 4 | (1)(2)(3)(4) | | | |
| | DRIVE DOWN (CLOSE) | COMMON (-) GRIVE DOWN (CLOSE) | | | |
| PC Board | | | | | |
| Manual override under | РСВ | Dip switch settings | | | |
| | | | | | |
| Potentiometer | | / Direction: from up to down | | | |
| Only on model | ° | | | | |



AT000/005/020/060/065/080 AT000-30/005-30/020-30/060-30/065-30/080-30

Retrofit option





400 Lebeau blvd, Montreal, Qc, H4N 1R6, Canada

www.neptronic.com

Toll free in North America: 1-800-361-2308 Tel.: (514) 333-1433 Fax: (514) 333-3163 Customer service fax: (514) 333-1091 Monday to Friday: 8:00am to 5:00pm (Eastern time)